

Service manual

OVERVIEW D SERIES

Doc-3302-5

DOC-3302-5

Title: OVERVIEW D SERIES – **Service Manual**
ID-no.: **DOC-3302-5**
Date: 2006-05
Revision: 08

	main issue	update
chapter 1	new	
chapter 2	new	
chapter 3	new	
chapter 4	new	
chapter 5	new	
chapter 6	new	
chapter 7	new	
chapter 8	new	
chapter 9	new	
chapter 10	new	

new: The corresponding chapters are new or completely revised.
corr.: Passages of the corresponding chapter were corrected; see modification bars.
add.: Passages of the corresponding chapter were added; see modification bars.

Document History

Modifications, which result in a new version, are indicated by a vertical bar.

Keep this sheet!

Trademarks

Brand and product names mentioned in this manual might be trademarks, registered trademarks or copyrights of their respective holders. All brand and product names mentioned in this manual serve as comments or examples and are not to be understood as advertising for the products or their manufacturers.

Copyright © 2004-2006 by Barco Control Rooms GmbH

Die Weitergabe sowie die Vervielfältigung aller Unterlagen, die von uns überlassen werden, deren Verwertung und Mitteilung ihres Inhaltes an Dritte ist nicht gestattet, soweit dies nicht ausdrücklich zugestanden ist. Urheberrechte, insbesondere auch solche an Software, werden nur insoweit übertragen, als es für die Erreichung des speziellen Vertragszwecks erforderlich ist. Zuwiderhandlungen können zu Schadensersatz verpflichten. Alle Rechte aus der Erteilung eines Patents oder der Eintragung eines Gebrauchsmusters verbleiben bei uns.

Copyright © 2004-2006 by Barco Control Rooms GmbH

All rights reserved. No part of this document may be copied, reproduced or translated. It shall not otherwise be recorded, transmitted or stored in a retrieval system without the prior written consent of Barco Control Rooms GmbH.

Guarantee and Compensation

Barco Control Rooms GmbH provides a guarantee relating to perfect manufacturing as part of the legally stipulated terms of guarantee. On receipt, the purchaser must immediately inspect all delivered goods for damage incurred during transport, as well as for material and manufacturing faults. Barco Control Rooms GmbH must be informed immediately in writing of any complaints.

The period of guarantee begins on the date of transfer of risks, in the case of special systems and software on the date of commissioning, at the latest 30 days after the transfer of risks. In the event of justified notice of complaint, Barco Control Rooms GmbH can repair the fault or provide a replacement at its own discretion within an appropriate period. If this measure proves to be impossible or unsuccessful, the purchaser can demand a reduction in the purchase price or cancellation of the contract. All other claims, in particular those relating to compensation for direct or indirect damage, and also damage attributed to the operation of software as well as to other services provided by Barco Control Rooms GmbH, being a component of the system or independent services, will be deemed invalid provided the damage is not proven to be attributed to the absence of properties guaranteed in writing or due to the intent or gross negligence on the part of Barco Control Rooms GmbH.

If the purchaser or a third party carries out modifications or repairs on good delivered by Barco Control Rooms GmbH, or if the goods are handled incorrectly, in particular if the systems are commissioned or operated incorrectly or if, after the transfer of risks, the goods are subject to influences not agreed upon in the contract, all guarantee claims of the purchaser will be rendered invalid. Not included in the guarantee coverage are system failures, which are attributed to programs or special electronic circuitry provided by the purchaser, e. g. interfaces. Normal wear as well as normal maintenance are not subject to the guarantee provided by Barco Control Rooms GmbH either.

The customer must comply with the environmental conditions as well as the servicing and maintenance regulations specified in this manual.

To:

- From:**

page

wrong

correct

wrong

Contents

1 Introduction.....	1-1
1.1 How this manual is organized	1-2
1.2 Styles and Symbols	1-3
2 Overview	2-1
2.1 General.....	2-2
2.2 Location of components.....	2-2
2.3 Overview of Projection Unit.....	2-3
2.4 Overview Illumination Unit	2-4
2.5 Pin Assignment of Power Connector	2-5
2.6 Pin Assignment Signal Connector	2-5
3 Maintenance work.....	3-1
3.1 Cleaning	3-2
3.1.1 Cleaning the screen	3-2
3.1.2 Cleaning the projection lens	3-2
3.1.3 Cleaning the entrance lens of the projection unit	3-2
3.1.4 Cleaning the UV/IR filter on the exit of the illumination unit.....	3-3
3.1.5 Cleaning the deflection mirror	3-3
3.2 Exchange of consumables.....	3-4
3.2.1 Replacement of filter pad	3-4
3.2.2 Replacement of Lamp Module	3-5
3.2.3 Unpacking a lamp module	3-6
3.2.4 Illumination unit with 2x200W lamps	3-10
4 Display defects.....	4-1
4.1 Defects related to the projector electronics.....	4-2
4.1.1 Scrambled image.....	4-2
4.1.2 White flashing.....	4-2
4.1.3 Flickering image	4-2
4.1.4 Half screen (only SXGA).....	4-3
4.1.5 Dancing pixels.....	4-3
4.2 Defects related to the DMD	4-4
4.2.1 Bright pixel.....	4-4
4.2.2 Unstable Pixel	4-4
4.2.3 Dark pixel	4-4
5 System messages and errors.....	5-1
5.1 Manual User Interface and LED Indication.....	5-2
5.1.1 Power Switch	5-3
5.1.2 Standby Switch	5-3
5.1.3 Active Lamp Selection Switch	5-4
5.1.4 Indication of Power LED.....	5-5

5.1.5 Indication of Lamp Door LED	5-5
5.1.6 Indication of the Status LEDs	5-6
5.2 OnScreen Menu	5-7
5.3 RS232 command	5-8
5.4 Error list	5-11
5.4.1 Lamp top / Lamp bottom	5-11
5.4.2 Fan	5-11
5.4.3 Over temperature	5-12
5.4.4 Under Voltage Error	5-13
5.4.5 Illumination unit read	5-13
5.4.6 Brightness	5-13
5.4.7 Lift error	5-14
5.4.8 Reference Search	5-14
5.4.9 Lamp door	5-14

6 Errors not detected by the system..... 6-1

6.1 Observed pheonomena	6-2
6.1.1 No power is available	6-2
6.1.2 Display remains dark	6-2
6.1.3 Lamp does not ignite	6-2
6.1.4 Lamp cannot be switched on	6-3
6.1.5 Lamp lift cannot be moved any longer	6-3
6.1.6 Only the background, but no data is displayed	6-4
6.1.7 Only one half of the picture is displayed (SXGA only)	6-4
6.1.8 Inhomogeneous light distribution	6-4
6.1.9 Picture shows dark shadows	6-5
6.1.10 Picture seems to be teared up or stripes are visible	6-5
6.1.11 Projector appears too dark	6-5
6.1.12 Brightness cannot be adjusted	6-5
6.1.13 DIS value remains constant	6-6
6.1.14 No OSD available	6-6
6.1.15 A new fan does not work	6-6
6.1.16 On the illumination unit, the appendix to connect the cooling hose is broken	6-6
6.1.17 Light exit window of illiumination unit damaged	6-6

7 Replacing of components 7-1

7.1 Fan Module	7-1
7.1.1 Procedure	7-1
7.2 Projection Unit	7-5
7.2.1 Procedure	7-5
7.3 DIS (Direct Illumination Sensor)	7-7
7.3.1 Procedure	7-7
7.4 Color Wheel Cartridge	7-8
7.4.1 Procedure	7-8
7.5 Electronic Frame	7-11
7.5.1 Procedure	7-13
7.6 Illumination Unit	7-15

7.6.1 Replacing.....	7-15
7.7 Internal Fan.....	7-17
7.7.1 Replacing.....	7-17
7.8 Fan and Motor Controller Board.....	7-19
7.8.1 Replacing.....	7-19
7.9 Power Supply Assembly.....	7-22
7.9.1 Replacing.....	7-22
7.9.2 Lamp Power Assembly	7-25
7.9.3 Replacing.....	7-25
7.10 Lift Motor	7-28
7.10.1 Replacing	7-28
7.11 X/Y Mirror Motors	7-31
7.11.1 Replacing	7-31
8 Field interventions.....	35
8.1 Service Tool for Lift Adjustment of OverView D Series (RSDLP33320)	36
8.2 Exchange of lubricant of lamp lift.....	40
8.3 Corrosion of light pipe	42
8.4 Replacement of input board	46
8.5 Cleaning of the projection unit	49
8.6 Check settings of the OverView D projection system.....	8-3
8.7 Illumination unit 200W: replacing the fan plate.....	8-5
9 Partslist.....	9-1
9.1 Consumables.....	9-1
9.2 Spare Parts (Sales Articles)	9-1
9.3 Spare Parts (internal products, not for sale).....	9-2
10 Hotline.....	10-1
10.1 Addresses.....	10-1

1 Introduction

This manual gives some hints and instructions how to replace and exchange components of the OverView D series.



This manual is for authorized personnel only and requires the highly responsible dealing with electric and electronic devices!



This manual contains highly sensitive and confidential information and is intended for internal use within Barco. No parts of it shall be distributed outside Barco Control Rooms.

1.1 How this manual is organized

This manual is divided into 9 chapters.

Introduction

explains the structure of the manual itself and the used typographic styles and symbols.

Overview

Shows the general design and the interaction of the components.

Maintenance work

Explains how to clean components and how to exchange consumables

Display defects

Describes observed display defects, their cause and how to repair them

System messages and errors

Explains how to read the system messages and what they stand for

Errors not detected by the system

Describes failures which are not auto-detected and gives hints how to solve these problems

Replacing of components

Gives instructions how to replace faulty components

Partslist

Lists the article numbers of the spare parts and consumables

Hotline

lists the addresses to contact if any problems occur.

Numbering

Chapters, pages, figures and tables are numbered separately. Chapters are indicated by a »point syntax«, e. g. **4.2.3**, pages by a »dash syntax«, e. g. **2-1**.

1.2 Styles and Symbols

The typographic styles and the symbols used in this document have the following meaning:

Bold	Labels, menus and buttons are printed in Bold font.
Condensed	Links to both other chapters of this manual and to sites in the Internet are printed condensed . In the on-line version of this manual all hyperlinks appear teal .
Courier	Names of files and parts from programs are printed in the Courier font.
Courier bold	Inputs you are supposed to do from the keyboard are printed in Courier bold font.



If you do not heed instructions indicated by this symbol there is a risk of damage to the equipment!



If you do not heed instructions indicated by this symbol there is a risk of electrical shock and danger to personal health!



If you do not heed instructions indicated by this symbol there is a risk of damage to parts, which are sensitive toward electrostatic charge!



If you do not heed instructions indicated by this symbol there is a risk to get harmed by sharp objects!



If you do not heed instructions indicated by this symbol there is a risk that parts may explode!



If you do not heed instructions indicated by this symbol there is a risk that hot parts impact persons or objects!



The sheet icon indicates additional notes.



Next to this icon you find further information.



This arrow marks tips.



Next to this icon you find important notes.

2 Overview

This chapter explains the design of OverView D series

2.1 General

The OVERVIEW D SERIES has a modular design and comprises, besides the mechanics, the following components which can be accessed from the rear:

- Illumination unit
- Projection unit
- Fan module

This manual describes how to replace these components and/or to exchange parts of it.

2.2 Location of components

The following picture gives an overview about the locations of the components of a projection module:



Figure 1
rear side location of components

1	Projection Unit
2	Illumination system (dual lamp system)
3	Power block
4	Filter
5	Dark Box
6	Mirror
7	Screen






Figure 2
projection unit and illumination unit are linked via a power cable and a data cable




As soon as the illumination unit and the projection unit are connected by the signal cable and/or the power cable, DO NOT disconnect either of these cables under operation or in standby!
Disconnect only when the system is completely powered off (all LEDs are off)!
Otherwise the trinamic board of the IU will be damaged.


2.3 Overview of Projection Unit




2.4 Overview Illumination Unit



2.5 Pin Assignment of Power Connector



2.6 Pin Assignment Signal Connector



As soon as the illumination unit and the projection unit are connected by the signal cable and/or the power cable, DO NOT disconnect either of these cables under operation or in standby!

Disconnect only when the system is completely powered off (all LEDs are off)!

Otherwise the trinamic board of the IU will be damaged.

3 Maintenance work

Maintenance work of OverView D comprises cleaning of components and exchange of consumables.

3.1 Cleaning

3.1.1 Cleaning the screen

Screens consist of single or double screen elements. Each screen element has a delicate optical screen surface structure dedicated to its functionality. The optical surface can easily be damaged if the screen is handled incorrectly. Only handle screens while wearing gloves with a soft texture (e. g. cotton gloves).

Avoid touching the rear beaded surface unnecessarily. It is easily damaged.



The screen is a high-precision optical component. It is made of plastic and is not scratch-proof. Only use a soft, damp cloth when cleaning.

If the screen is only slightly dusty or is showing particles a vacuum cleaner with a soft bristle or a feather duster is recommended. Clean compresses air can be used, but it makes the screen statically charged, attracting airborne particles. The brushing direction should always be along the optical structures in the screen (circular in case of fresnel).

If the dirt on the screen is heavier, possibly from fingerprints, soft lint-free cloth or paper towel can be used. If required the screen may be cleaned with a cleaning agent, such as ordinary window cleaner with ammonia (not alcohol). Never apply cleaning solution directly onto the screen surface. Instead, add cleaning agent to the cloth or towel, then wipe the surface. It is important that the screen should be completely dry after treatment.



Never use cleaning agents with solvents as these may destroy the screen. Also, never rub hard or persistently on the screen in order to remove stains, as this will cause deformations in the surface which will appear as stains.

Don't store screens at temperatures exceeding 40°C (104°F)

3.1.2 Cleaning the projection lens

To minimize the possibility of damaging the optical coating or scratching exposed lens surface, it is recommend to try to remove any material from the lens by blowing it off with clean, dry deionized air.

Subsequently use Isopropane to clean the lens.

Proceed as follows :

- Soak a lens paper with Isopropane and take it in one hand
- Take a dry lens paper in the other hand
- Now work literally hand-in-hand: Wipe the lens with the wet paper, and immediately dry it with the other paper.
- Always wipe lenses in a single direction. Do not wipe back and forwards across the lens surface as this tends to grind dirt into the coating.

3.1.3 Cleaning the entrance lens of the projection unit

Use Isopropane to clean the lens.

Proceed as follows :

- Soak a lens paper with Isopropane and take it in one hand
- Take a dry lens paper in the other hand
- Now work literally hand-in-hand: Wipe the lens with the wet paper, and immediately dry it with the other paper.

3.1.4 Cleaning the UV/IR filter on the exit of the illumination unit

Use Isopropane to clean the filter.

Proceed as follows :

- Soak a lens paper with Isopropane and take it in one hand
- Take a dry lens paper in the other hand
- Now work literally hand-in-hand: Wipe the filter with the wet paper, and immediately dry it with the other paper.

3.1.5 Cleaning the deflection mirror

To minimize the possibility of damaging the surface, it is recommend to try to remove any material from the mirror by blowing it off with clean, dry deionized air.

Use a microfibre cloth and carefully wipe the mirror. Take care not to apply any pressure: this will de-adjust the mirror alignment!

3.2 Exchange of consumables

Projection modules of the OverView D series have two consumables: the filter pad and the lamp.

3.2.1 Replacement of filter pad

Depending on the quality of supplied air, the filter pad has to be replaced in intervals of about 10000 hours. The filter class is G3. The frame is clearly marked with air flow direction.

Product	Description
R9842800	Filter pad

To replace a filter pad, proceed as follows:

- Switch the projector in Standby mode.
- Switch off power by pressing **OFF**.



Switch off the equipment before replacing the filter pad in order to avoid severe contamination of OverView D

- Lift the cover of the filter pad slightly and remove it.




Figure 3
Removing the cover and the filter pad

- Remove the filter pad.
- Insert the new filter pad as indicated on its frame. The arrow marks the air flow direction.
- Insert the cover of the filter pad and press it slightly down.
- Disconnect the air tubes from the illumination unit and the projection unit
- Let the fan run for 1 minute
- Connect the air tubes to the illumination unit and the projection unit.
- Switch on power by pressing **ON**.



Never push against a used air filter pad. The trapped dust particles will be released by doing so!

3.2.2 Replacement of Lamp Module

Product	Description
R9842020	Lamp Module for OverView D Series, 120W
R9842440	Lamp Module for OverView D Series, 100W

The used type of lamp is a UHP (UltraHighPerformance)-Lamp. There are two mechanisms that define the end of life:

1. The burst of the inner part of the lamp bulb (burner). The burner is protected from its environment by a reflector box with a glass pane, which is located in the front, so that this burst does not cause a damage to the environment of the lamp.
2. The lamp voltage, which increases during ageing has reached a critical limit which forces the lamp ballast to switch off.

The projector does not distinguish between these two mechanisms.



The lamp has a nominal operation time of 6000 hours (120W lamp) or 10 000 hours (100 W lamp). In case the lamp exceeds this operation time, It is not necessary to replace it! Only replace broken lamps!



In case of a lamp failure, the respective status LED (lamp top: top LED, lamp bottom: mid LED) blinks slowly red.

The power LED blinks slowly green to indicate a non critical error. For acknowledge, push up the standby switch for 6 seconds.

Lamp failures can only be detected if the lamp is running.

OVERVIEW D is designed as a dual lamp system. In case a lamp is broken, replace it immediately to ensure to have a good lamp in case the other lamp fails, too.

If there is no lamp for replacement on stock, DO NOT remove the broken lamp. The cooling concept requires that two lamps are installed!

After the replacement of a lamp module, the new serial number has to be entered, and the lamp optimization procedure has to be carried out.



Bevor replacing a lamp module, this lamp has to be inactivated!

Only open the lamp door when the lamp door LED shines red!

3.2.3 Unpacking a lamp module

The lamp packing consists of a polystyrene box with two identical shaped layers, the top layer and the bottom layer. A label indicates how to place the box




Place the box on a table.
Cut the label on the joint between top layer and bottom layer.
Remove the top layer.
Fetch the lamp on the top and lift it outside.



Take care not to touch the glass top of the reflector!



In case it is a lamp module of 200W, you have to remove the polystyrene cushions first:





If you accidentally made any fingerprints on the glass top of the reflector, clean the glass top with alcohol before inserting the lamp module!

Carefully check the lamp module: in case there are any small remains of the polystyrene, take a paintbrush and remove them!



Note that there may be laws concerning disposal and recycling of burnt-out lamps in your country! Please contact your local authorities to get further information!



To pack the lamp module, proceed in the reversed order, please! Don't touch the glass top of the reflector! Take hold on the fitting and place the lamp module upside down onto the lower layer. Press the upper layer firmly against it, "opening" on top side, and close the box with adhesive tape!

Removing a Lamp

The lamp module must be replaced if a fault occurs.

With OverView D series, lamps are hot swappable and can be replaced while the equipment is on. When opening the lamp cover, the lamp driver will be disconnected, and there is no risk of electrical shock. However it is NOT recommended to open the lamp door if the lamp door LED does not show red.



Only open the lamp door when the lamp door LED shines red! The hot lamp is at high pressure. Do not open the lamp housing before the lamp has cooled down! Wait at least about 5 minutes after switching off the lamp.



Always hold the lamp by its socket, and never on the glass bulb or reflector! Use fabric gloves when replacing!

- Use a hexagon key size 3.
- To open the lamp door, a quarter turn counterclockwise will do
- Open the lamp door.



Figure 4
opening the lamp door

Now you can see the lamp, fixed into its position by means of a securing ring [1].




Figure 5
inside the lamp housing

- Press the securing ring axial towards the lamp, and turn it counterclockwise until the hooks are released from the guide rods.



Figure 6
the securing ring

- Remove the securing ring
- Withdraw the lamp module. While withdrawing, the plug is disconnected.



Figure 7
withdrawing the lamp module

Disposing Lamp Modules



Note that there may be laws concerning disposal and recycling of burnt-out lamps in your country! Please contact your local authorities to get further information!

Inserting a Lamp Module

The following description applies if the lamp has already been removed as described above and the lamp cover is still opened.

- Fetch the lamp module on its housing. The power socket is on the right side.
- Insert the lamp carefully. Take care that the "tubes" slide on the guide rods [2].




Figure 8
lamp and lamp housing

- Mind the position of the fingers: the force is to apply on the outer part of the module



Figure 9
applying the force on the lamp module

- Press the lamp module tightly into its socket
- Apply the securing ring on the lamp and press it in axial direction while turning
- Turn the securing ring until its hooks click round the guide rods.



Figure 10
inserting the securing ring

- Close the lamp door
- Use the hexagon key and lock the lamp door by turning the screw a quarter turn clockwise.

In case the operation mode has been Hot Standby , the lamp will be switched on automatically.

In case the operation mode has been Cold Standby or Auto switch, the lamp will be switched on automatically in case it becomes the active lamp (i.e. in case of a lamp failure of the other lamp or after the switch cycle.



After the replacement of a lamp module, the new serial number has to be entered, and it is highly recommended to select the lamp optimization procedure.

In emergency cases the lamp optimization procedure can be skipped for the moment and carried out later.

3.2.4 Illumination unit with 2x200W lamps

Due to the higher light output of the 200W lamps compared to 100W lamps or 120W lamps, the illumination to house the 2x200W lamp has a dedicated cooling concept. In addition the lamp modules are different.

The lamp module must be replaced if a fault occurs and if the lamp does not succeed in re-ignition again.

3.2.4.1 Removing the lamp module

- Use a hexagon key size 3 (the key is provided with the system)
- To open the lamp door, a quarter turn counterclockwise will do
- Open the lamp door.



Figure 3-11
opening the lamp door

Now you can see the lamp, fixed into its position by means of a "locking slider".




Figure 3-12
Position of slider

Push the locking slider to the right.



Figure 3-13
Locking slider

- Withdraw the lamp module. While withdrawing, the plug is disconnected.




Figure 3-14
withdrawing the lamp module

- When the lamp is removed, you see the two guiding rods on the upper right/lower left and the additional fan for cooling.




Figure 3-15
guiding rods and additional fan, lamp module with plug

3.2.4.2 Inserting a lamp module

The following description applies if the lamp has already been removed as described above and the lamp cover is still opened.

- Fetch the lamp module on its housing. The power socket is on the right side.
- Insert the lamp carefully. Take care that the "tubes" slide on the guide rods.
- Press the lamp module tightly into its socket.
- Lock the lamp into its position by pressing the locking slider to the left.




Figure 3-16
inserting the lamp and locking it

- Close the lamp door
- Use the hexagon key and lock the lamp door by turning the screw a quarter turn clockwise.



The lamp door must not be open for more than 15 minutes. If not closed within this period, the projector will show a warning, and then go to standby after another 5 minutes.

If the operation mode of the projector has been **Hot Standby**, the new lamp is immediately switched on.

In case the operation mode has been **Cold Standby** or **Auto switch**, the lamp will be switched on automatically in case it becomes the active lamp (i.e. in case of a lamp failure of the other lamp or after the switch cycle).



After the replacement of a lamp module, the new serial number has to be entered, and it is highly recommended to select the lamp optimization procedure.

In emergency cases the lamp optimization procedure can be skipped for the moment and carried out later.

4 Display defects

If the displayed image suffers from strange effects, try to categorize them according the following list in order to find the right solution.

4.1 Defects related to the projector electronics

4.1.1 Scrambled image

Occurrence:	typically once per hour up to once per day
Duration:	typically a half to 3 seconds
Appearance/Observation:	the whole frame looks jagged and flashing, an alternation of the CW speed is hearable during the failure. It sounds like changing the gear. We have seen that projectors with that behavior can also resync the color wheel but nothing is visible on the screen. Best method to detect such projectors is to check the sound of the color wheel!
Background:	Problem with CW motor driver which introduces a resynchronization of the CW
Solution:	ECP 400642 which is to be done on the formatter board

4.1.2 White flashing

Occurrence:	typically once per hour up to once per day
Duration:	up to 50 ms (very short!)
Appearance/Observation:	This failure introduces a kind of short flashes on the screen. They can appear as white flashes on a full black screen or as black flashes on white screen. If some test patterns are applied, the flashes might appear as a kind of ghost of the actual pattern which is shifted. No change of the CW speed is hearable during this failure. Background: problem with CW beat signal processing on PICO2 board. In that case from time to time individual pulses of the CW are not processed, which introduces the flashing.
Solution:	Upgrade to firmware 2.01.

4.1.3 Flickering image

Occurrence:	Continuously
Duration:	NA
Appearance/Observation:	Under this term we bundle a couple of issues. Type 1: The image looks jagged and is flashing all the time – reason for this might be a noisy CW beat signal that introduces more than one CW sync pulse per revolution. Try an exchange of the CW. Type 2: The image is stable but seems to change color all the time. This can be seen best on a full white image. It is an indicator that the lamp is not synchronized to the CW. Try to reboot the engine. If error still occurs, exchange IU. Type 3: The image is changing intensity quite fast and the IU is giving an undervoltage error. This can be seen for all kind of image content. Reason is an alternating lamp output power. Try to use another IU. If problem has disappeared, exchange defective IU. Reason could also be faulty capacitors on the boards. Change the PFC and the SMPS board!

4.1.4 Half screen (only SXGA)

Occurrence:	Continuously
Duration:	as long as the projector stays switched on
Appearance/Observation:	With this failure only one screen half (preferably the left half – in a darkbox) shows an image while the other stays dark. Background: The DMD in a SXGA projector is operated by two identical ASICs. In that case the slave ASIC has been shut down. This can be introduced by electronic interference or failure on formatter board
Solution:	Reboot the engine. If the failure still occurs or after short time, check which formatter board programming version is used: In the OSD, select Status Identification long. Examine the point 6: if the version is lower than 1.02, an upgrade should be done to version 1.02. Exchange the PU.

4.1.5 Dancing pixels

Occurrence:	Occurrence: continuously, sometimes depending on temperature
Duration:	Forever
Appearance/Observation:	They only appear on special test pictures like the yellow rose or in gray scales. They appear as single pixels that show up in a characteristic color (R,G,B) that is different to the background. Most times they are oriented like contour lines and sometimes they tend to move (dancing). If the image is frozen and observed as the background logo they also appear frozen. Background: Problem with the DVI input board, most probably insufficient soldering paste under SIL chip that is required for cooling purposes.
Solution:	Use optical cable. If the problem still exists, exchange DVI input board.

4.2 Defects related to the DMD

4.2.1 Bright pixel

Occurrence:	Continuously
Duration:	Forever
Appearance/Observation:	This is a single pixel that is shining white all the time, independently from image content. Background: This is a micro mirror that got stuck. Actually this should not happen due to outgoing inspection at TI and incoming inspection at Barco.
Solution:	Exchange of DMD. This cannot be repaired. If the projector's age is less than 1 year, it is subject of TI warranty.

4.2.2 Unstable Pixel

Occurrence:	Continuously
Duration:	Forever
Appearance/Observation:	<p>This is a single pixel or mirror that does not operate in sequence with parameters loaded into memory. The unstable pixel appears to be flickering asynchronously with the image and might only be perceivable at special background. It doesn't necessarily show up as a bright pixel on a black background.</p> <p>Background: This is a micro mirror that can't be addressed reliable by the electronics. Actually this should not happen due to outgoing inspection at TI and incoming inspection at Barco.</p>
Solution:	Exchange of DMD. This cannot be repaired. If the projector's age is less then 1 years, it should be subject of TI warranty.

4.2.3 Dark pixel

Occurrence:	Continuously
Duration:	Forever
Appearance/Observation:	<p>This is a number of pixels that stay black all the time, independently from image content.</p> <p>Background: This is are micro mirrors that got stuck. The quality specification of TI allows up to 4 dark pixels for XGA and up to 12 dark pixels for SXGA which we have to accept. Dark pixels must not be adjacent to each other.</p>
Solution:	Exchange of DMD only if more than 4 dark pixels or dark pixels next to each other can be found. This cannot be repaired. If the projector's age is less than 1 year, it is subject of TI warranty.

5 System messages and errors

To localize an error, the OverView D series provides several points of information.

5.1 Manual User Interface and LED Indication

In case of a mal function of OverView D, please check the LED indication first

The manual user interface located at the rear of OverView D includes the switches of the illumination unit [1], [2], [3], the LED's of the illumination unit [6], and the LED's of the lamp doors, [4, 5].

The manual user interface is intended to operate the projection module when servicing. By evaluating the status of the LEDs, errors can be analyzed.

The control elements of OverView D are located on the rear of the system. They include 3 switches and in total 6 LEDs.



Figure 17
rear side: control elements

Item	Refers to	Function
1	Power switch	Rocker switch, Power ON (up) or OFF (down)
2	Standby switch and Power LED	also used for the acknowledge of errors (reset)
3	Active lamp selection switch	Rocker switch, top: select lamp top bottom: select lamp bottom
4	Status LEDs (Lamp top, Lamp bottom, Fan)	Informs about the operation status of the two lamps and the fan
5	Lamp door bottom LED	indicates if the lamp door may be opened or not
6	Lamp door top LED	indicates if the lamp door may be opened or not

5.1.1 Power Switch

The power switch [1] connects/disconnects the projector from the mains. Once switched on, the projector should be disconnected from the mains only for servicing.



Do not press the power switch while the projector is running. The projector has to be switched to Standby first!

5.1.2 Standby Switch

The Standby Switch [2] has 3 positions: neutral (not pushed), up (pushed to the top), down (pushed to the bottom).

The switch is slope sensitive and reacts when changing from one position to the other. To prevent operation errors, a minimum time is required for pushing. After sending a command (after pushing the switch), the next command can only be sent after the release of the switch for at least 0.5s.

In case the power switch [1] is off, there is no reaction.

Projector status	Power LED	Action	Push time	Function
Standby (no error)	red, static	Up		switching on the projector
		Down		only in combination with active lamp selection switch [3], for servicing only
Standby (error)	red, blinking fast	Up	6sec	reset of error after servicing
		Down		no function
On (no error)	green, static	Up		reserved for future use
		Down	3sec	switching off the projector (standby)
On (error)	green, blinking slowly	Up	6sec	reset of non critical error
		down	3sec	switching off the projector (standby), reset of non critical error
Projector is starting up or shutting down	blinking yellow	Up		no function
		Down		no function

5.1.3 Active Lamp Selection Switch

The Active Lamp Selection Switch [3] has 3 positions: neutral (not pushed), up (pushed to the top), down (pushed to the bottom).

The switch is slope sensitive and reacts when changing from one position to the other. To prevent operation errors, a minimum time is required for pushing. After sending a command (after pushing the switch), the next command can only be sent after the release of the switch for at least 0.5s.

In case the power switch [1] is off, there is no reaction.

Projector status	Power LED	Action	Function
Standby (no error)	red, static	Up	Lamp Top becomes active, lift is going down
		Down	Lamp bottom becomes active, lift is going up
Standby (no error) Standby switch pushed down	red, static	Up	reserved for future use
		Down	reserved for future use
Standby (error)	red, blinking fast	Up	no function
		Down	no function
On (no error)	green, static	Up	Lamp Top becomes active, lift is going down
		Down	Lamp bottom becomes active, lift is going up
On (no error) Standby switch pushed up	green, static	Up	reserved for future use
		Down	reserved for future use
On (error)	green, blinking slowly	Up	no function
		down	no function
Projector is starting up or shutting down	blinking yellow	Up	no function
		Down	no function

5.1.4 Indication of Power LED

Color	Blink Mode	Meaning
Red	Static	Projector is in Standby-Mode (=Off)
Green	Static	Projector is in Operation-Mode (=On)
Yellow	Blinking/Fast	Projector is starting up
Yellow	Blinking/Slowly	Projector is switching off
Green	Blinking/Slowly	Projector is in Operation-Mode (=On); a Non Critical Error occurred; Check status for more information; then press Standby Switch/On for acknowledge
Red	Blinking/Fast	Projector off (Standby) because of a Critical Error; Service required; after service press Standby Switch/On for acknowledge
Green	Blinking/Fast	Projector is in Operation-Mode (=On); a Critical Error occurred; Check status for more information.

5.1.5 Indication of Lamp Door LED

Color	Blink Mode	Meaning
Red	Static	lamp is switched off, lamp door can be opened for servicing
Green	Static	lamp is switched on, DON'T open the lamp door! (in case the door is opened, the lamp is switched off automatically)
Yellow	Static	lamp is switched on for Hot Standby mode or Auto Switch mode (17 minutes changeover time), DON'T open the lamp door! (in case the door is opened, an error occurs)



Only open the lamp door in case the lamp door LED shines red.

5.1.6 Indication of the Status LEDs

	Color	Blink Mode	Meaning
Top LED (status LED of Lamp Top)	Red	Static	lamp is switched off, cooled down
	Green	Static	lamp is switched on,
	Yellow	blinking fast	lamp is starting (15 minutes)
	Yellow	blinking slowly	lamp is cooling down
	Red	blinking slowly	an error occurred, lamp is switched off, cooled down, service required!
Mid LED (status LED of Lamp Bottom)	Red	Static	lamp is switched off, cooled down
	Green	Static	lamp is switched on,
	Yellow	blinking fast	lamp is starting (15 minutes)
	Yellow	blinking slowly	lamp is cooling down
	Red	blinking slowly	an error occurred, lamp is switched off, cooled down, service required!
Bottom LED (status LED of Fan)	Red	Static	Fans are off
	Green	Static	Fans are on
	Red	blinking slowly	Fan error, at least one fan failed service required!

5.2 OnScreen Menu

The OSD includes an **Error** menu which shows critical and non-critical errors. Critical errors will result in shutting down the projector within a given time. If the error is fixed within this time limit, the projector will continue running.

The critical errors are:

- Fan
- Over Temperature
- Under Voltage
- Lift
- Reference Search
- Lamp Door




Figure 18
error menu

In case an error occurs, the respective checkbox is ticked.

The values are checked regularly; in case the cause of the error has been resolved, the tick will be removed automatically.

Explanation of the errors, cf [Error list](#)

5.3 RS232 command

The items listed in the OSD menu **Error** correspond to the error bits of the **System Error**. If an error occurs, the respective error bit is set (and the checkbox in the OSD menu is ticked).

The status can be viewed by means of the RS232 tools which visualizes these error bits. If they are set, the respective checkbox is ticked.

The values are monitored continuously. If the cause of the error is resolved, the error bit is reset and the checkbox is cleared.




Figure 19
the RS232 tool visualizes the projector status



If the DIS sensor is always busy, this is a clear indication that the DIS sensor is out of order. Check also the IR receiver: Make sure it is enabled before trying to operate the projector by means of the IR remote control!

Of course you can also use the RS232 protocol and retrieve the values via the commands **Projector Status Read** and **Get System Errors**.

Projector_Status_Read

As a global check it is recommended to read the **Projector Status..** In case the system error bit is set (bit 7), detailed information will be provided via the command



In addition to bit 7, which indicates if a system error has occurred, also examine bit 3 and bit 13.

Bit 3 indicates if the DIS sensor is busy. If the DIS sensor is always busy, this is a clear indication that the DIS sensor is out of order.

Bit 13 indicates if the IR receiver is enabled. Make sure that it is enabled before trying to operate the projector by means of the IR remote control!

Projector status (and system errors) are checked regularly, if the cause of the error has been resolved, the error bit will be reset.

Syntax:	Start	Addr	cmd	Sub cmd	Data[0]	Data[1]	Data[2]	Data[3]	Data[4]	Chksu	Stop
										m	
	0xfe	PA	0x67							chc	0xff
Answer	Start	Addr	cmd	Sub cmd	Data[0]	Data[1]	Data[2]	Data[3]	Data[4]	Chksu	Stop
										m	
	0xfe	PA	0x67		wValue					chc	0xff
	Data[0]: Bit 1:0			Projector	0: starting, 1: Stopping, 2: Stopped, 3: Running						
	Bit 2			Freeze	0: Normal, 1:Freeze						
	Bit 3			DIS sensor	0: free, 1: busy						
	Bit 4			RS232 LCC	0: last sent command not completed, 1: is completed						
	Bit 5			OSD initialization	0: process not active, 1:process active						
	Bit 6			Saving Data	Internal data is currently saved in EEPROM						
	Bit 7			System Error	Indicates a system error – details see						
	Get_System_Error										
	Bit 8:9			Lamp Top	0: starting, 1: cooling down, 2:Off, 3:On						
	Bit 10:11			Lamp Bottom	0: starting, 1: cooling down, 2:Off, 3:On						
	Bit 12			OSD being updated	0: no action, 1:new OSD data is created						
	Bit 13			IR Enabled	0: IR receiver enabled, 1: disabled						

Get_System_Error

In case bit 7 of Data[0] of **Projector_Status_Read** is set, the command **Get_System_Error** results in a detailed error description.

Syntax:	Start	Addr	cmd	Sub cmd	Data[0]	Data[1]	Data[2]	Data[3]	Data[4]	Chksu	Stop
										m	
	0xfe	PA	0xfe	0x0c						chc	0xff
<i>Answer</i>	Start	Addr	cmd	Sub cmd	Data[0]	Data[1]	Data[2]	Data[3]	Data[4]	Chksu	Stop
										m	
	0xfe	PA	0xfe	0x0c	wValue					chc	0xff
	Data[0]: Bit 0, 1,15			High	Indicates an error						
		Bit 0		Lamp Top							
		Bit 1		Lamp Bottom							
		Bit 2		Fan	Fan speed not ok, or fan stopped						
		Bit 3		OverTemperature	Overtemperature in illumination unit or on Power Factor Correction detected						
		Bit 4		UnderVoltage	Undervoltage of Power Factor Correction detected						
		Bit 5		Illumination Unit read	Communication to illumination unit is not ok						
		Bit 6		Brightness 1	In combination with bit 10, see explanation below						
		Bit 7		Lift	End position not reached, or lift motor defect						
		Bit 8		RefSearch	Search of reference position of the optical dimmer was not successful						
		Bit 9		Lamp Door	Lamp door is open						
		Bit 10		Brightneess 2	In combination with bit 6, see explanation below						

5.4 Error list

5.4.1 Lamp top / Lamp bottom

A lamp error occurs if the active lamp fails during operation and if the ignition of the inactive lamp fails, respectively.

The lamp error bit is set, and the lamp lift can no longer be moved!

This error has to be reset manually.



Press the On/Res. switch for about 6 sec. on the rear of the system to reset the error.

Reset the error

- once without doing anything else to make sure that the lamp is really broken
- after a lamp exchange

Depending on the operation mode, the behavior of the system differs.

In **Hot Standby** mode, after resetting the error, the lamp is ignited. If ignition is successful and the lamp has been switched on, the lift can be moved again. If ignition is a failure, the lamp error is set again and the lift remains locked.

In **Cold Standby** mode, since the replaced lamp is the inactive lamp, after resetting the error, there is no lamp check, and the lamp remains switched off. The lift can be moved again. If then the system changes the active lamp by means of the lift, the new lamp is tried to be lighted. If it is a flop, the error bit is set again, and within about 5 seconds, the projector switches back to the lamp which has been the active one. Then the lift is locked again.



In Cold Standby, after switching the active lamp, the lamp which has been active at that time is only switched off if the second lamp succeeds in being switched on.

5.4.2 Fan

OverView D series employs two fans: one which is located behind the filter pad frame and connected to the illumination unit and the projection unit, and one which is located beneath the bottom lamp.

Both fans are mandatory for operating OverView D, and in case one of them is out of order, it need to be replaced immediately!

The status of both fans together can be derived from the fan LED. (The fan LED is the bottom LED of the three status LEDs).

Fan LED green: both fans work

Fan LED is red (static): fans are off!

Fan LED is blinking red: a fan error has occurred. At least one fan is not running



The fan error is an auto-updated error. It's of no use to reset the error manually since the fan is monitored continuously. In case the error is solved, error bit is reset automatically. In case the error persists, the error bit is set (again).

In case the error is not reset automatically, you have to find out which of the both fans caused the error.

To check the fan located on the rear side of the projection module:

- Listen if you can hear it running. In case you don't hear anything, proceed as follows:
- Open the middle cover of the rear side to get access to the projection unit.
- Check the cabling between the illumination unit and the outer fan.
- Disconnect the air hose from the projection unit. Check if you can feel any air stream.
- In case you don't feel any air blowing, shut down the projector.
- Replace the fan box.



Disconnecting a hose from the projection unit and checking the air stream is not allowed to last more than 1 minute, otherwise damage to the projection unit will be done.

In case the fan located on the rear of the projection module works, and the fan LED is blinking red, check the fan located beneath the bottom lamp:

- In case the projector is running in hot standby mode, switch it to cold standby operation mode.
- Select the top lamp to be the active lamp.
- Open the lamp door of the bottom lamp.
- Remove the bottom lamp temporarily
- Check visually if the fan is running, and try to feel the air stream.
- Take care not to harm your fingers by touching the fan!
- In case it does not run, replace it.

5.4.3 Over temperature

A sensor which is located behind the tilt mirror in the illumination unit checks the temperature. In case a critical temperature (40°C) is reached, the over temperature bit is set, the shut down cycle counter starts its countdown, and the projector is shut down within five minutes to prevent the system from severe damage.



If desired, the countdown counter can be disabled and thus over temperature protection..
It is highly recommended NOT to switch of over temperature protection.

In case the temperature drops within the countdown period below the critical limit, the countdown counter stops, and the over temperature bit is reset automatically.

Reset the error

- after repair has been done (e.g. re-connecting the air tube, exchange of the fan)



After repair, press the On/Res. switch for about 6 sec. on the rear of the system to reset the error.
This can only be done in standby mode!

5.4.4 Under Voltage Error

This error occurs if the voltage of the power factor correction board is below a critical limit.

If DMD parking is enabled (default: disabled), the DMD will be parked after 10ms, i.e. black screen.

If the error is resolved during this time (practical not possible), the DMD parking will not be done.

Only auto-reset of the error, no manual reset possible!

5.4.5 Illumination unit read

This error occurs if there is no I²C communication between the illumination unit and the projection unit.

This error usually occurs when starting up the projector.

If this error bit is set, the dimmer motor and the motor of the mirrors in the illumination unit are not running.

- Switch off the projector, check the power cable and switch it on again.



It is not recommended to manually reset of the error, since this only affects the error bit, but not the error itself.

5.4.6 Brightness

Brightness is related to two bits, bit 6 and bit 10, (brightness 1 and brightness 2) and to evaluate the status, it is mandatory to look at the combination of these two bits.

Brightness 1 (bit 6)	Brightness 2 (bit 10)	Description
0	0	Brightness is ok
1	0	Brightness is not at target, but too high, the mechanical dimmer is on its lower limit
0	1	Brightness is not at target, the mechanical dimmer is still adjusting
1	1	Brightness is not at target, but too low, the mechanical dimmer is on its upper limit

After a new target value of the brightness has been set, the brightness error (0,1) usually occurs up to 10 seconds while the system tries to adjust itself to the new target.

During standard operation, the error can show up for approximately one hour. If it never disappears, it is recommended to check and the lamp.



Manual reset of this error makes no sense.

5.4.7 Lift error

This error occurs if the lift did not reach the switches at its upper and lower end position, respectively.



Manual reset of this error makes no sense.

To solve the problem, move the lift again.

If this error occurs after each change of the active lamp, shut down the projector and manually move the lift. If it is not easy going, try to find out the obstacle in the lift moving way and remove them.

A lift error can be an indication for a not well balanced lamp lift. In particular, either the spring that balances the mass of the lamp lift against gravity is too weak or the mechanical friction of the lift is too high.

Rebalance of the lamp lift has to be done in production. Send back the illumination unit for repair.

As an intermediate solution until spare illumination unit becomes available: misalign the end switches: Try to place the lower switch (top lamp) 0.5 mm higher and /or the upper switch (bottom lamp) 0.5 mm lower.

5.4.8 Reference Search

This error occurs if the mechanical dimmer cannot find its home position.

Firmware release 2.0 provides a new algorithm which ensures that there is at least some light on the screen.

With Firmware release 1.x the screen remains dark.

Switch off the projector and switch it on again. If the error still remains, exchange the projection unit.

5.4.9 Lamp door

This error occurs if a lamp door is opened. When the error bit is set, a counter starts, and if the door is not closed within the counter cycle of 15minutes, the projector will shut down. If the door is closed within this counter period, the error bit and the counter will be reset, and the projector performs a lamp lift readjustment after closing the door. This is required since the lamp lift could be at a shifted position.

6 Errors not detected by the system

This chapter lists errors which are not directly related to the monitored status. The following chapters try to give you hints when to replace which component.

6.1 Observed phenomena

6.1.1 No power is available

Description	No power is available, although the power cord is properly connected, and all fuses are ok.
Recommendation	All LEDs are off, and they remain dark when you try to switch on the projector, and you do not hear the click of the relay board Replace the fuses on the main power connection of the illumination unit (Fuse type F 5X20 T 3A15 H UL) Check the power supply of your building. If it is ok, replace the power supply assembly of the projector. Try to download the latest FMW (if this state is achieved after interrupted firmware upload)
Final solution	Replace the illumination unit.

6.1.2 Display remains dark

Description	The lamp is on and running, but the display remains dark.
Recommendation	Check if the lamp LED is green. (In case it shows red, the lamp is off, in case it is blinking yellow, the lamp is starting (fast blinking) or cooling down (slow blinking).
	Check if the optical dimmer works properly and passes light onto the DMD.
	If both lamps and dimmer are ok, proceed as follows: In case you have a spare electronic frame, replace the electronic frame and then check if the problem is solved. In case you don't have a spare electronic frame, replace the entire projection unit.
Final solution	Replace electronic frame or entire projection unit, respectively.

6.1.3 Lamp does not ignite

Description	A lamp does not ignite
Recommendation	Replace the lamp. In case a new lamp does not ignite, check the color wheel. If it is rotating, the lamp driver might be broken.
Final solution	Replace the lamp power assembly

6.1.4 Lamp cannot be switched on

Description:	The lamp cannot be switched on
Recommendation	Check the status LED and/or the error bits.
Explanation	If a lamp is broken, the corresponding status LED indicates this error by a red slow blinking. This error can also be seen in the status tab of OverView D in Apollo or by reading the status by means of RS232 command: In case the lamp is broken, the system error bit is set.
Solution	Replace the lamp
	In case it still cannot be switched on, check the color wheel
Explanation:	If the color wheel is broken, the electronic of the formatter board switches off the lamp! The color wheel is synchronized with the lamp.
Recommendation	<p>Shut down the projector.</p> <p>Check the cable of the projection unit and the illumination unit. Make sure that they are properly connected and the screws are fastened.</p> <p>Open the cover of the color wheel in order to be able to see what's going on.</p> <p>Switch on the projector.</p> <p>Start the lamp.</p> <p>Case 1:</p> <p>The color wheel starts rotating. In case it does not, it is broken. Replace the color wheel.</p> <p>Case 2:</p> <p>The color wheel starts rotating, the lamp is ignited and burns for 1 or 2 seconds, then the lamp switches off., and the color wheel slows down.</p> <p>While the color wheel slows down, the display starts flickering, the colors get undefined, finally the display is black.</p> <p>The lamp is switched off.</p> <p>After starting the projector, you get the following feedback of the RS232 interface:</p> <p>Lamp cooling – projector starting up – lamp cooling down.</p>
Final solution	Replace the lamp and repeat the procedure. In case this lamp also switches off, replace the color wheel

6.1.5 Lamp lift cannot be moved any longer

Description	The lamp lift cannot be moved any longer
Recommendation	<p>In hot standby mode, the lamp cannot be moved any longer if the inactive lamp is broken. Check the error status to see if a lamp error occurred.</p> <p>Replace the lamp.</p> <p>Check the error bits to see if a lift error occurred.</p> <p>Replace the Fan and Motor Controller board in case the lamp lift does not move although both lamps are ok.</p> <p>Replace the lift motor.</p>
Final solution	Replace the illumination unit.


6.1.6 Only the background, but no data is displayed

Final solution	Replace the electronic frame
----------------	------------------------------

6.1.7 Only one half of the picture is displayed (SXGA only)

Description	With SXGA projectors, only one half of the picture is displayed
Recommendation	Try to restart the projector
Explanation	On the formatter board of SXGA projectors there are two DDP1000 chips. In case only one half of the picture is displayed, this is a clear indication that one of the chips does not work. Since formatter boards are not replaced in the field, the entire projection unit has to be replaced!
	Perform the steps as described in section 4.1.4 If the problem still exists,
Final solution	Replace the projection unit.

6.1.8 Inhomogeneous light distribution

Description	On a projection module, the light distribution is very inhomogeneous
Recommendation	<p>1. Check the x/y mirror unit</p> <p>Open the middle rear cover of the projector.</p> <p>Unscrew the projection unit and lift it out.</p> <p>Fix it to the dark box upside down, as shown in the picture:</p>  <p>Look into the light aperture of the illumination unit where the x/y mirror is located. Check the x/y mirror. If it is broken, you have to replace the x/y mirror unit. If it is ok, check the mirror motors. To check the motors, proceed as follows:</p> <p>Switch on the projector.</p> <p>After being switched on, the x/y mirror unit drives to its home position. If the springs do not move, you have to replace the x/y mirror unit.</p> <p>2. Check the lamp lift for correct position, cf. package insert of the lift adjustment tool RSDLP33320 how to do this.</p>
Explanation	An inhomogeneous light distribution is an indication for the wrong position of the x/y tiltable mirror.
Final solution	Replace x/y mirror unit

6.1.9 Picture shows dark shadows

Description	The picture shows dark shadows
Recommendation	Clean the projection lens and the mirror of the dark box.
Final solution	Replace projection unit.

6.1.10 Picture seems to be teared up or stripes are visible

Final solution	Replace the electronic frame
----------------	------------------------------

6.1.11 Projector appears too dark

Description	After the setup of a Display Wall, a projector may appear too dark, and exchanging of the lamps does not help.
Recommendation	Check the dimmer setting: Select Set brightness in the service menu of the OSD. In relative mode, brightness has to be set to 100.
	Check the correct position of the sealing between projection unit and illumination unit.
	Check the cleanliness of the condenser lens of the projection unit and the UV/IR filter of the illumination unit, respectively.
	Make sure that no lift error is indicated. In the event of a lift error, the active lamp is not at its correct position. Change the active lamp. If the lift error still remains, change the illumination unit.
Final solution	Change the illumination unit.

6.1.12 Brightness cannot be adjusted

Description	The projector is running, the picture is ok, but the brightness cannot be adjusted.
Recommendation	Launch the OSD, activate the service menu, and select Set Brightness . Check the indicated DIS value. If the DIS value is zero, open the appendix where the DIS sensor is located. Check if it is properly connected. Take a torch and illuminate it directly: The displayed brightness value should change. In case there is no influence, first replace the sensor itself.
	In case the problem still exists, it might be a corrupt cable to sensor controlling circuit or the board itself. To prove a broken sensor controlling circuit, proceed as follows: In the OSD service menu, select DIS calibration factor. Write down this value (should be 1 if CAST was not done yet). Set the calibration factor to 1 and the correction factor to 0. Set brightness to relative mode of 100%. Now the DIS value should be above 100. In case it is below 100 but the projector is as bright as other projectors, replace the electronic frame.
Final solution	In case it is below 100 but the projector is as bright as other projectors, replace the electronic frame.

6.1.13 DIS value remains constant

Description	In relative brightness mode, the DIS value remains the same no matter what percentage of brightness is selected.
Explanation	The dimmer does not work
Recommendation	Toggle between "dimmer enabled" and "dimmer disabled". Whenever the dimmer is enabled, it searches for the home position. In case the dimmer is broken, a Reference Search error occurs. This error can be read by RS232.
	If there is a spare color wheel cartridge, it can be replaced first in order to check if it is the dimmer motor which is broken. (With the color wheel cartridge dismounted, you might try to turn the dimmer wheel. If it is stuck, you do not need to insert a color wheel cartridge again, you then have to replace the entire projection unit.)
Final solution	If the error is located to be caused by the dimmer itself, you have to exchange the entire projection unit.

6.1.14 No OSD available

Final solution	Check the video source for correct timing. Replace the electronic frame
----------------	--

6.1.15 A new fan does not work

Description	The fan does not work although it has been replaced
Explanation	The fan cable might be broken
Recommendation	Check the fan cables (beep). In case the cables are ok, it is the fan and motor controller board which has to be replaced.
Final solution	Replace the Fan and Motor Controller Board

6.1.16 On the illumination unit, the appendix to connect the cooling hose is broken

Final solution	Replace the illumination unit.
----------------	--------------------------------

6.1.17 Light exit window of illumination unit damaged

Description	The illumination unit has to be replaced in case the light exit window towards the projection unit looks strange, e.g. if the filter glass is broken.
Final solution	Replace the illumination unit.

7 Replacing of components

7.1 Fan Module

Product	Description
RSDLP32790	Fan Box Repair Kit

For safe operation, the unit has to be cooled. The fan provides a circulation of air of about 19 l/min. which is sufficient to carry off the heat produced mainly by the two lamps.

7.1.1 Procedure

**Tools:****Torx key size 30****Drill (size 3.2mm)**

Figure 20
Fan box core unit and cooling hose

Besides the fan box core unit, the Fan Box Repair kit includes all necessary fixation material and the two cooling hoses.




Figure 21
OverView D rear view

To replace the fan module, proceed as follows:

- Power down the projection module.
- Remove the top rear cover [1] and bottom rear cover [2]
- Disconnect the cooling hose from the projection unit.
- Disconnect the cooling hose from the illumination unit




Figure 22
cooling hoses

- Disconnect the fan cable from the illumination unit



Since the cable is not only plugged into the fan box, but also fixed to it on one of the corner of the fan box core unit, it is recommended to disconnect it from the illumination unit!

- Loosen the screws of the fan rear cover
- Remove the complete fan rear cover with the fan module from the cube.
- Remove the cooling hoses from the fan module.



Figure 23
Fan rear cover

- Remove the filter pad.



Figure 24
Fan rear cover, filter pad removed

- Remove the faulty fan box by loosening the 6 rivets with a drill (size 3.2mm).



Figure 25
position of rivets



Figure 26
position of rivets



Figure 27
drilling out the rivets

- Remove the old fan box core unit and insert the new one.
- Tighten the new fan box core unit using the screws with the counter nuts and washers.
- Connect the two cooling hoses:
On the back side of the fan box core unit, connect the short hose (60cm)
On top of the fan box core unit, connect the long hose (95cm)
- Install the fan box rear cover with the new fan box core unit into the darkbox.
- Fasten the screws of the fan box rear cover.
- Connect the short cooling hose (on back of fan box core unit) to the projection unit.
- Connect the long cooling hose (on top of fan box core unit) to the illumination unit
- Connect the fan power cable at the illumination unit.
- Install the two rear covers [1, 2] on the dark box.
- Insert the filter pad.

7.2 Projection Unit

Product	Description
R9841920	Projection Unit SXGA
R9841921	Projection Unit XGA
R98419215	Projection Unit XGA Firmware 3.x
R9842670	Projection Unit SXGA+
R98426705	Projection Unit SXGA+

The projection unit comprises the image processing electronics, the DLP chip and the optics. Due to the modular design, the entire projection unit can be replaced without the need of replacing other parts, e.g. the illumination unit or the fan.



As soon as the illumination unit and the projection unit are connected by the signal cable and/or the power cable, DO NOT disconnect either of these cables under operation or in standby!

Disconnect only when the system is completely powered off (all LEDs are off)!

Otherwise the trinamic board of the IU will be damaged.

7.2.1 Procedure

Required tool	Torx key size 30
Required tool	Torx key size 10



Figure 28
Projection unit




Figure 29
Overview D, rear view

To replace the projection unit, proceed as follows:

- Remove the rear cover [4].
- Disconnect the cooling hose from the projection unit.




Figure 30
Overview D, rear cover removed

- Disconnect the signal cable[5], power cable[6], data cable[1] and the cables for remote control. [3], [4] as well as the fan power cable [2]
- Loosen the 6 fixation screws.
- Take out the projection unit.

To install a projection unit, proceed in the reversed order.

7.3 DIS (Direct Illumination Sensor)

partnumber	description
R764103	DIS (direct illumination sensor) (internal spare part)

The direct illumination sensor is part of the projection unit. It is located into the black tube next to the connection of the cooling house.



Figure 31
location of DIS

7.3.1 Procedure

To replace the DIS, proceed as follows:

- Twist off the cover of the black tube.



Figure 32
black tube, cover twisted off

- Disconnect the cable (CT4, yellow).
- Remove the sensor.
- To install a new sensor, proceed in the reversed order.

When the new sensor is in place, a re-calibration is required. This has to be done by CAST.

7.4 Color Wheel Cartridge

Product	Description
R9841950	Color Wheel Cartridge

7.4.1 Procedure

Required tool	Torx key size 10
---------------	------------------

The color wheel cartridge [1] is part of the projection unit.



Figure 33
location of color wheel cartridge

- To de-install a color wheel, unscrew the torx fixation screws [A], [B].
- Remove the black cover. Now you can see the color wheel cartridge [2] and the optical dimmer [1].




Figure 34
color wheel cartridge and optical dimmer

- Before removing the color wheel, all cables have to be disconnected from the color wheel connection board in the projection unit:

- Disconnect the flex foil [5] to the color wheel motor: Lift the small ears on each side of the flex connector with e.g. a small screw driver and take out the flex foil
- Disconnect the cable to the color wheel sensor [4] (yellow, 3pole)
- Disconnect the cable to dimmer motor [3] (black, red, blue, green, 4pole)

Now you can remove the color wheel cartridge: Pull it straight out!



Pull the color wheel cartridge straight out. Do not tilt by pulling!

Take care that the light pipe is not touched!

Take care that the mechanical dimmer plate (grease!) is not touched!




Figure 35
color wheel cartridge [2] with connections:
3: to dimmer motor, 4: to color wheel sensor, 5: to color wheel motor

The new color wheel is packed into an antistatic bag. Please note the label indicating the color wheel index for XGA and SXGA resolution. After replacement of the color wheel, this new index has to be entered into the system by the RS232 color wheel exchange tool since this method also changes the index value in the factory default settings. (In special circumstances also the service menu of the OSD can be used.)



Figure 36
color wheel cartridge in antistatic bag, the color wheel index is written on the label



Only remove the antistatic bag when installing the color wheel. Never store the device without its protective package!

Electronic discharge will damage the device!

Therefore remember the following precautions:

- Use a grounded workplace
- Wear a ground wrist strap
- Discharge your body's static electricity by touching a grounded surface.



Figure 37
color wheel cartridge

- Open the bubble wrap and carefully lift out the color wheel which is packed into a protective foam sheet.
- Open the protective foam sheet.

The yellow 3-pole cable connected to the color wheel sensor is extra protected by a shorting plug.



Only remove the protective shorting plug when connecting the cable to the color wheel connection board in the projection unit!

To insert a new color wheel cartridge, proceed in the reversed order.



While mounting the flex foil to the color wheel connection board, make sure that the flex foil is inserted straight and the connector is properly closed.

7.5 Electronic Frame


Spare part	Description
R9841940	OV D SPARE ELECTR. FRAME ASM XGA/SXGA (XGA: only old systems, fmw 2.x)
R9842820	OV D SPARE ELECTR. FRAME ASM XGA, SXGA+, Firmware 3.x



Please note:

For new systems XGA, SXGA+ (Firmware 3), the DIP switch on the PICO2+ board has to be configured according the resolution!

The Electronic Frame is a component of the projection unit. It includes the input board [3], the PICO2/PICO2+ board [4], and the light sensor [1].





The input board provides all interfaces [2] for

- Data (DVI)
- RS232 Remote Control In (Sub D 9, F)
- RS232 Remote Control Out (Sub D 9, M)
- Power (Sub D 25 M)
- Signal (Sub D 25 F)
- IR Sensor (CT 3)

The PICO2/Pico2+ board receives the data, processes it, and transmit it to the DMD formatter board.

The light sensor (DIS – Direct illumination sensor) measures the intensity of the light. These values are then compared to the desired brightness values, and the optical dimmer is adjusted accordingly.

The Electronic Frame has to be configured according the resolution: for SXGA+ resolution, both dips are in the the OFF position, whereas for XGA resolution dip 1 is OFF, dip 2 is ON:



Replacement of the Electronic Frame does not only require to configure the switch, but also to subsequently program the inputboard! (Service Menu|Maintenance|Program Input board).

This step ensures that the correct files are loaded!

7.5.1 Procedure



To replace the Electronic Frame, there is no need to de-install the projection unit!

Required Tool	Torx key size 10
Hexagon key	Size 3

To replace the Electronic Frame, proceed as follows:

- Disconnect all cables from the projection unit (power cable, signal cable, data cable, remote-control cabling, cable to IR sensor)
- Take a hexagon key size 3 and turn the "door" screw of the projection unit thus releasing the locking mechanism of the front cover of the projection unit.
- Push the front cover in left direction to remove it.




Figure 38
projection unit, cover open

- Disconnect the two flex foil cables [3], [4] which connect the Pico2/Pico2+ board with the formatter board: Lift the small ears on each side of the flex connector with e.g. a small screw driver and take out the flex foil
- Disconnect the power cable [2] (MD8, red and black) from the formatter board
- Disconnect the cable from the color wheel connection board [1] (CT 11, yellow)
- Unscrew the screws on the front of the Electronic Frame.
- Unscrew the torx screws on the left side of the projection unit (this side is already part of the Electronic Frame). The white arrow points to a hidden screw. The screw labeled 1 need not be removed (keyhole), only loosen it.



Figure 39
projection unit, left side

- Pull the frame forward and take it out.

To install a new electronic frame, proceed in the reversed order.



While mounting the flex foil to the Pico2/Pico2+ board, make sure that the flex foil is inserted straight and the connector is properly closed.

When re-mounting the front cover, it is recommended to first fit in the guide rods at the bottom of the front cover into the slits of the Electronic frame, then fit in the top of the front cover, and at last push the entire front cover to the right and finally lock the screw.

7.6 Illumination Unit

Part number	Description
R9842650	Illumination unit 120W
R9842460	Illumination unit 100W
R9842470	Illumination unit 200W

Due to the modular design, the illumination unit can be exchanged without any impact on the optical adjustment of the projection unit.

The illumination unit comprises the power supply, the lamp lift armed with two lamps and the related electronics.

The sub components can be individually replaced, too.



As soon as the illumination unit and the projection unit are connected by the signal cable and/or the power cable, DO NOT disconnect either of these cables under operation or in standby!

**Disconnect only when the system is completely powered off (all LEDs are off)!
Otherwise the trinamic board of the IU will be damaged.**

7.6.1 Replacing

Required Tools	Torx key size 30
Required Tools	Torx key size 15



Figure 40
illumination unit

To remove the illumination unit, proceed as follows:




Figure 41
rear side

- Remove the top rear cover[1] and the center rear cover [4]
- Loosen the securing screws A, B on the right rear cover.
- Move A, B to top and lock them.
- Push the air duct up to release the illumination unit.
- Disconnect the cooling hose from the illumination unit
- Remove the left side cover[5]
- Disconnect the main power plug
- Disconnect the power cable[1], the data cable [2], and the fan power cable [3] from the illumination unit.



Figure 42
illumination unit: cabling

- Unscrew the top fixation screws of the illumination unit.
- Loosen the bottom fixation screws of the illumination unit. Due to the keyhole, they don't need to be entirely removed.
- Push the entire illumination unit to the right and lift it out.

To install a new illumination unit, proceed in the reversed order.

7.7 Internal Fan

Part number	Description
V322050	FAN AX 12V 10LS 40DB S 60, internal spare part, no sales article!

The internal fan is located at the bottom of the lamp lift. It is mainly used to stabilize the streaming direction of the cooling air.

7.7.1 Replacing

Required Tools	Precision screw driver
----------------	------------------------

To replace the internal fan, proceed as follows:

- Switch the projector to Standby mode.
- Move the lamp lift up (Lamp Bottom is in front of the optics)
- Open the bottom lamp door.

Now you can see the internal fan mounted onto the bottom plate of the lamp lift. Since every lift movement will bend or stretch the fan cable, it is passed through a metal spring. Thus the cable won't be squeezed or crushed.




Figure 43
internal fan

Both ends of the spring are hooked on the base plate of the lamp lift and on the bottom of the illumination unit, respectively.



Figure 44
internal fan: spring is hooked

- Unhook the springs.
- Subsequently unplug the cable of the internal fan.




Figure 45
internal fan: fan cable

Now you can loosen the screws on the internal fan.



It is recommended to place a sheet of paper on the bottom grid of the illumination unit in case the screws fall down.

To install a new fan, proceed in the reversed order.



**When installing the new fan, make sure that its cable is on the left side!
Do not forget to hook the spring on the bottom and on the top plate!**

7.8 Fan and Motor Controller Board

The Fan and Motor Controller Board is located at the bottom of the illumination unit. For replacing, the illumination unit has to be de-installed.

7.8.1 Replacing

Part number	Description
R9842010	Fan and Motor Controller Board

Required Tools	Torx key size 10 Cutter/Knife Screw driver size
----------------	---

- De-install the illumination unit.
- On the front side of the illumination unit, loosen the two screws indicated in the picture.



Figure 46
screws to be loosend

- Loosen the screws on the bottom and on the sides.




Figure 47
screws to be loosend

Now the Fan and Motor Controller board can be accessed.



Figure 48
Fan and Motor Controller board

The Fan and Motor Control Board has a lot of connections to the other components of the illumination unit. These cables have to be disconnected.



Before disconnecting the cables of the old board, it might be recommended to color the connection on the new board and the cable with an Edding pencil in order to facilitate the reconnection of the cables to a new Fan and Motor Controller unit.



Mind the fixation of cables on the sheet metal of the Fan and Motor Control Board unit by means of a cable fastener. When cutting, take care not to hurt the cables!

The following sketch shows the relevant cables/connectors when replacing the Fan and Motor Controller board




Figure 49
Fan and Motor Controller board: cables and connectors

Number	Type	Destination
1	MD-2, red and black	Internal Fan
2	MD-2, red and black	External Fan
3	CT-3, yellow	Lamp 1 Control
4	CT-3, yellow	Lamp 2 Control
5	CT-4, yellow	Lamp Lift
6	MD-4, red, black, brown, brown	Status Control
7	CT-6 , yellow (3 cables)	Mirror Motor, x direction
8	CT-6 , yellow (3 cables)	Mirror Motor, y direction
9	CT-3 , yellow	Temperature Sensor
10	CT-10, yellow	SMPS power supply

- Exchange the Fan and Motor control board
- Reconnect the cables
- By means of cable fastener, re-fix the yellow cable bundle to the new black sheet metal.
- Fold the Fan and Motor Control board into the illumination unit.
- Tighten the screws.

7.9 Power Supply Assembly

Part number	Description
R9841990	Power Supply Assembly

The Power Supply Assembly is a PBC located in the illumination unit and comprises the Switch Mode Power Supply board (SMPS) and the Power Factor Correction board (PFC).

7.9.1 Replacing

Required Tools	Torx key size 10
----------------	------------------

- De-install the illumination unit.
- Unscrew the back cover of the illumination unit and take it off.



Only remove the indicated screws! Otherwise the internal boards are unscrewed!




Figure 50
unscrew back cover of illumination unit


Now the Power Supply Assembly can be accessed.



Figure 51
Power Supply Assembly

1	Power Supply Assembly
2	Lamp Power Assembly
3	Lamp Lift, Mirror, and Mirror Motor

For easier explanation of the location where the various cables have to be disconnected, have a look on the Power Supply Assembly as spare part:



1	Mains (Line or Neutral)
2	Mains (Line or Neutral)
3	Ground / Earth



**The ground connector is in horizontal direction,
Line connector and Neutral Connector are both in vertical direction!**

Label	destination
4	Safety Switch on Relay Board, 4pole: black, black, red, red
5	To Relay Board
6	To Fan and Motor Control Board
7	To Formatter Board (Power)
8	To Fan and Motor Control board, CT-10, yellow
9	To Pico2 Board (Power)

On the black cube labeled A, the lamp drivers are connected:




Figure 52
connection of lamp drivers

A	Lamp driver connection
---	------------------------

- To replace the Power Assembly Unit, disconnect all indicated cables/connections.
- Loosen the screws which fix the unit to the black metal sheet housing.



- Take out the Power Assembly Unit.

To install a new Power Assembly Unit, proceed in the reversed order.

7.9.2 Lamp Power Assembly

Part number	Description
R9842000/ R764450K	Lamp Power Assembly, 120 W PowerPack/ Upgrade Kit Lamp driver 120W Compact to 120W PowerPacck
R9842450	Lamp Power Assembly, 100W

The Lamp Power Assembly includes the lamp driver for lamp 1, the lamp driver for lamp 2, and the relay board. The 120 W Power Pack will become the spare part for the existing compact driver assembly. The spare part number (R9842000) does not change.

In case a different lamp power assembly is used, also the sticker which comes with the spare part kit has to be placed onto the illumination unit's label!

7.9.3 Replacing

Required Tools	Torx key size 10
----------------	------------------

- De-install the illumination unit.
- Open the back cover the illumination unit

Now the Lamp Power Assembly [2] can be accessed:



Figure 53
Power Supply Assembly



Figure 54
Lamp Power Assembly

To remove the Lamp Power Assembly, proceed as follows:

- Disconnect the strong black lamp driver cables from the "black square".
- Disconnect all cables from the Relay Board:




Figure 55
cabling



It might be useful to color the cables and the connections on the new board with an Edding to prevent mixing up when re-connecting!

Label	Type	Destination
1	CT-3, yellow	Bypass Lamp Control Bottom, to Fan and Motor Control Board
2	CT-3, yellow	Bypass Lamp Control Top, to Fan and Motor Control Board
3	CT-4, yellow	Power, from SMPS
4	MTA-156 Connector white, cables red, red, black, black	Safety Switch, to PFC

- Loosen the fixation screws of the metal plate.
- Take out the Lamp Power Assembly.




Figure 56
removing Lamp Power Assembly

To install a new Lamp Power Assembly, proceed in the reversed order.



After the replacement of the Lamp Power Assembly, a safety check has to be performed.
Select hot standby mode.
Open the door of the inactive lamp. The lamp should be switched off!
Open the door of the active lamp. The lamp should be switched off!



Make sure that in the OSD the correct lamp driver is selected!
(Service|Maintenance|Lampdriver)

7.10 Lift Motor

Part number	Description
R9841980	Lift Motor Assembly

The Lift Motor moves the lamp lift up and down

7.10.1 Replacing



Figure 57
lift motor

Required Tools

Torx key size 10
Ring spanner size 7
cutter
Teflon tape

To replace the lift motor, it is necessary to remove the Lamp Power Assembly first.




Figure 58
removing Lamp Power Assembly

- Remove the Lamp Power Assembly.




Figure 59
lift motor

- Cut the cable fastener




Figure 60
cutting the cable fastener

- Disconnect the cable (yellow, CT-4, from Fan and Motor Control Board)
- Unscrew the nuts.




Figure 61
nuts to be unscrewed

- Lift out the motor.




Figure 62
lift motor removed

- Install the new lift motor in the reversed order.
- When the nuts are tightened, apply the teflon tape on the gear rack and move the gear wheel.




Figure 63
apply teflon tape




Figure 64
moving the gear wheel

The position of the gear wheel and the tightening of the fixation screws is correct when there are clear marks visible on the teflon tape:




Figure 65
marks on the teflon tape

7.11 X/Y Mirror Motors

Part number	Description
R9841970	Mirror Unit Assembly

The position of the mirror which directs the emitted light into the light tube can be changed in x and y direction. The mirror and the stepper motor which drives the mirror make the spare part kit Mirror Unit Assembly.

7.11.1 Replacing



Figure 66
x/y mirror unit assembly

Required Tools	Torx key size 10 Special tool: angled torx key size 10 Ring spanner size 7 cutter Teflon tape
----------------	---

To replace the Mirror Unit Assembly, the Lamp Power Assembly has to be de-installed first:




Figure 67
cabling



It might be useful to color the cables/connections with an Edding pencil in order not to mix them up when reconnecting.

- Cut the cable fastener.
- Disconnect all cables.
- Loosen the screws.




Figure 68
loosen the screws




Figure 69
loosen the screws

- Lift out the mirror unit assembly




Figure 70
lift out x/y mirror unit

To install a new Mirror Unit Assembly, proceed in the reversed order.

The mirror plate is hooked to the motor plate via springs.




Figure 71
mirror plate hooked to the motor plate

In case the mirror has to be replaced, bend a paper clip to create a tool to remove/apply the springs:




Figure 72
bend paper clip

When the mirror plate is removed, the special pins of the stepper motors are visible:




Figure 73
pins of stepper motor

8 Field interventions


This chapter includes all the the documents which have been created for field interventions.

8.1 Service Tool for Lift Adjustment of OverView D Series (RSDLP33320)

Qty	Product	included	checked by
1	Reference caliper ring R824996		
1	Adhesive measurement sticker label nonius		
1	Lamp door blocker R825003		
1	Working instruction		



Pos. 1: caliper ring



Pos.2: nonius label



Pos.3: lamp door blocker



The readjustment procedure described in this document is required for all Overview D projectors that have been produced before July 2003 which are to be operated with firmware Rel. 1.0 or higher.

It is mandatory to do the readjustment together with the upgrade from beta releases 0.30 or 0.31 to the official release 1.0 of the related projection unit. The document is valid for both XGA and SXGA versions.

All illumination units with manufacturing date July 2003 and later (see product label) are already adjusted in a way to be compatible to Rel. 1.0 and higher. For them no readjustment is required.

Please check for the completeness of the contents!

Detailed description of readjustment

1. First check if readjustmt is required. Check product label of IU. Go ahead if the IU was manufactured before July 2003. See fig. 1



Figure 74

Product label of Illumination unit. Check for manufacturing date.

2. Download firmware release 1.0
3. Remove the sheet metal plate between the two lamp doors, see fig. 2



Figure 75

Remove the sheetmetal plate between top and bottom lamp doors.

4. Remove the two lamps.
5. Define reference positions of lamp lift for top lamp by using the reference caliper R824996 and mark them with the adhesive measurement sticker „label.nonius“, see fig. 3, fig. 4




Figure 76

Fixation of the reference position ring. Note the correct orientation of the ring. The lift is in the correct position if it wrapped around the barrel that supports the condenser lens.




Figure 77

Placement of the measurement sticker. Tape the sticker half to the upper lift housing and half at the backplate of the IU while the lamp lift is kept in position with the reference ring. Take care not to cover the hole for the safety switch. After fixing it, cut it into two pieces along the dotted line

6. Cut the sticker into two pieces along the middle line, see fig. 4.
7. Define reference positions of lamp lift for bottom lamp by using the reference caliper R824996 and mark them with the adhesive measurement sticker „label.nonius“. Same procedure as step 5.
8. Cut the sticker into two pieces along the middle line. Same procedure as step 6.
9. Mount the two lamps again, bypass the lamp door safety switches by using the door switch blockers. See figure 5. Turn on the engine.



Caution: keep away from the lamps during the start up phase. During ignition a voltage up to 25 kV is applied. Take care not to harm your fingers by clamping them in the lamp lift.



Figure 78

Insertion of the lamp door switch blockers. Insert the blockers as shown in the picture.

10. Measure the displacement of the end positions for top and bottom lamp by addressing them as active lamp and utilizing the cut measurement stickers. See fig. 6.




Figure 6

Read out the end switch displacement. The vernier scale shows two columns of labels. If the left zero line is below the right zero line the left label column is to be used; if the left zero line is above the right zero line, the right label column is to be used.

Left picture: the end switch position is too low by 0.6 mm.

Right picture: the end switch position is too high by 1.5 mm.

11. Switch off the engine.

12. Dismount the Illumination unit.
13. Use a caliper to measure the height of the top adjustment screw at the current position. Turn the screw to adjust for the displacement measured in step 7 (bottom lamp). Control the correct adjustment by remeasuring the height of the screw head. See fig. 7.




Figure 79

Adjustment of the end switch position for the bottom lamp. The related screw is located at the top side of the illumination unit close to the opening of the air exhaust. It is locked with non removable paint. Use a caliper to measure the initial position of the screw and turn it to achieve the displacement that was measured before.

14. Same for bottom adjustment screw: Measure initial height of screw head, turn the screw to adjust for the displacement measured in step 5 (top lamp). See fig. 8.




Figure 80

Adjustment of the end switch for the top lamp. The adjustment screw is located at the bottom side of the illumination unit almost in the middle of the width.

The procedure is the same as for the top lamp end switch.

15. Mount illumination unit again in darkbox, fix power cables, an cables, air tube.
16. Recheck lamp positions by means of the measurement sticker.
17. If a difference larger than 0.2 mm can be observed, repeat steps 11 to 15.
18. Check error status while switching between the two active lamps. Lamp lift error must not show up!
19. Mount again the sheet metal plate between the lamp doors. Remove the door switch blockers.

If a lift error should occur:

This is an indication for a not well balanced lamp lift. In particular, either the spring that balances the mass of the lamp lift against gravity is too weak or the mechanical friction of the lift is too high.

Two options

Rebalance lamp lift – this is to be done in production. Send back the illumination unit for repair.

As an intermediate solution until spare illumination unit becomes available: misalign end switches. Try to place the lower switch (top lamp) 0.5 mm higher and /or the upper switch (bottom lamp) 0.5 mm lower.

8.2 Exchange of lubricant of lamp lift

Requirements:

Lubricant Winix 2300 (B1909197)

Cleaning tissue (R3790001)

Service Tool for Lift Adjustment of OverView D Series (RSDLP33320)

Diluent



The diluent is highly flammable! The cleaning procedure may only be performed when the illumination unit has totally cooled down (takes about 30min.), otherwise there is a danger for explosion!

Do not inhale the diluent! When applying, wear protective gloves!

Due to aging processes of the lubricant used with the lamp lift in OverView D, lift moving might be hampered or blocked at all. Therefore the lubricant has to be removed from the guide bars of the lamp lift and subsequently a new lubricant has to be applied.

Removement is done by cleaning the bars with a lint free paper tissue sucked with diluent (or turpentine). The new lubricant is of type Winix 2300.

When looking at the mechanics of the lamp lift, it can be seen that on the right side the entire bar is enclosed by surrounding material, whereas on the left side close contact is only half round the bar.



To remove the old lubricant, proceed as follows:

- Switch the projection module to standby.
- Switch off the mains. Unplug the power cable from the wall outlet.
- Open the lamp doors. Let the system cool down!

In case the system has been illuminated by lamp top, the lift is in the down position, and the upper guide bars can be seen looking into the upper lamp door opening.

Start with the right bar:

- Suck the cleaning paper with diluent.
- Insert the paper tissue round the bar, and move it up and down while simultaneously applying pressure and rotating the paper. This will remove the grease from the rear and from the side. Also wipe the front side of the bar!
- Proceed until the paper does no longer show any marks of grease.

Now remove the lubricant from the left bar. Inserting the paper like on the right bar will probably be impossible, but as seen above, due to the half enclosure only, grease will be mostly on front and on the side. Nevertheless try to reach round the bar and clean it properly until no marks are left on the paper.



Move the lamp lift by hand into its upper position. Now you have access to the bottom guide bars. Clean them according the instructions given for the upper guide bars. Mind not to damage the spring on the left!

After the old lubricant has been removed, the bars have to be greased with the Winix 2300 silicon paste:

- Put some of the lubricant on a clean lint-free paper,
- Fold the paper and distribute the lubricant evenly.
- Subsequently apply the silicone to the guide bars on bottom and on top.

When the lubricant has been applied to all accessible parts of the guide bars, manually move the lamp lift up and down to distribute the lubricant evenly. Repeat moving the lift 5 times. It should be easy-going without squealing. After switching on the projection module, move the lift 5 times up and down by changing the active lamp from lamp top to lamp bottom to lamp top and so on.

Use the Service Tool for Lift Adjustment of OverView D Series (RSDLP33320) to check the lift position!

8.3 Corrosion of light pipe



The procedure described below shall not be performed without having participated in the respective training! Violation of this pre-condition will inevitably lead to considerable damage of the optical components of the projection unit!





Optical components are highly sensitive! Utmost care has to be taken not to scratch the surfaces!

About light pipe corrosion

Light pipe corrosion is described e.g. by the AHD 24173 "Light pipe mirror coating flakes off".

Due to a corrosion reaction of the front ends of the light pipe of the projection unit, the displayed image shows dark borders especially around the edges. This effect is best visible when a grey background is applied. The following pictures show the corrosion of the light pipe and the dark border.



Check for corrosion of the light pipe

- Display an image with 60% grey.
- Carefully check the edges for dark borders, especially on the top of the image



In case dark borders are visible, make sure that they are not caused by dust on the screen!

In case dust of the screen can be excluded, a visual inspection of the light pipe is necessary to find out if the dark borders are caused by corrosion of the light pipe.

Preparation of visual inspection




To prevent the electronic components from damage due to electrostatic discharge, wear a grounded wrist wrap and discharge your body's static electricity by touching a grounded surface

- Unplug all cables from the projection unit.
- Unplug the power cable from the wall outlet.
- Apply the cover onto the lens. De-mount the projection unit and put it into an ESD protective bag to prevent it from electrostatic damage.
- Remove the electronic frame: Disconnect the two flex foil cables, the power cable and the cable from the color wheel connection board.



Use the shorting plug to prevent the color wheel connection board from damages due to electrostatic discharges!



Visual inspection of the light pipe



Make sure to wear rubber (latex) gloves (sweating fingers risk corrosion!) and the wrist wrap to prevent the equipment from damages caused by electrostatic discharges.


Optical components are highly sensitive! Utmost care has to be taken not to scratch the surface.

It's strictly forbidden to touch the light pipe! Take utmost care not to touch it with bare fingers or dirty gloves.



Never clean the light pipe. It's only allowed to blow it with compressed air. When blowing, make sure to held the can in upright position, cf. RINF9002 about cleaning the projection unit.

Do not speak in the direction of the mirror surface! (Spittle!)

- Put the projection unit on a table.
- De-mount the color wheel cartridge. As soon as the yellow 3-pole cable of the color wheel is disconnected from the color wheel connection board in the projection unit, apply the shorting plug to prevent the color wheel from damage due to electrostatic discharge!



- Turn the dimmer wheel manually until the max. opening is in front of the light pipe.
- Use a torch to illuminate the light pipe from the bottom.
- Look through the condenser lens CL2 and check for corrosion damage on top of the light pipe.




To check for corrosion on the bottom side of the light pipe, proceed as follows:

- Use a torch on top of CL2 and illuminate the light pipe.
- Very carefully place a small mirror between the bottom of the light pipe and the relay barrel.
- Check the bottom side of the light pipe for corrosion damage.



Take care not to touch the light pipe or the relay barrel with the mirror or with your hand, our fingers!



- In case there are any signs of light pipe corrosion, the entire projection unit needs to be replaced!
- Re-assemble the projection unit.
- For repair, send the projection unit to Noida.

If there is no corrosion of the light pipe visible, continue checking the projection unit to find out the reason for the dark borders.

8.4 Replacement of input board

About the input board

The input board is a component of the electronic frame of the projection unit. All interfaces are located on the input board:

- DVI: data
- Sub D 9, F: RS232 Remote Control In
- Sub D 9, M: RS232 Remote Control Out

The current input board showed a hardware bug: In spite of a present source, in special situations the background (color bars) was displayed. This was a clear indication that the data stream has been interrupted due to a hardware bug.

This bug has been localized and fixed on the new input board. To update the projection units, the input board has to be replaced.

Required tools

- New input board R7639085 (PBC 781414-03)
- Wrist wrap
- ESD protective bag
- Torx key size 10
- Hexagon key size 3
- Socket spanner size 5 and size 5.5

Preparation




It is mandatory to take all precautions to prevent the equipment from damage caused by electrostatic discharge:

wear a grounded wrist wrap

discharge your body's static electricity by touching a grounded surface.

When de-installed, place the electronic frame into an ESD protective bag!

- Switch the projector to standby.
- Switch of the mains and unplug the power cable from the wall outlet.
- Remove the rear cover of the projection unit.



- Fasten the wrist wrap to the projection unit and put it on. Discharge your body's static electricity.
- Disconnect all cables from the projection unit.



Use the shorting plug to prevent the color wheel connection board from damages due to electrostatic discharges!



- Loosen the screws of the electronic frame.
- Remove the electronic frame and put it in the ESD bag.

Procedure: step by step




Replacing of the input board of the electronic frame has to be done in a well-lit, clean, dust free and smoke free area.

Make sure to wear the wrist wrap to prevent the equipment from damages caused by electrostatic discharges.



- Unplug the red power cable.
- Loosen the fixation screws of the RS232 interfaces and the DVI interface.
- Loosen the four fixation screws of the board.







- Carefully lift up the input board a little bit to have easier access to the flex foil cables. Lift the small ears on the side of the flex foil connectors and unplug the cables.
- Withdraw the input board.
- Now you have good access to the yellow RS232 cable. Unplug the cable.
- The new input board comes with the fixation screws fixed on the DVI interface. These screws are different to the screws of the old input board! Loosen these screws.
- Loosen the fixation screws of the RS232 interfaces (with the previous version of the input board, these interfaces were pop riveted, now they are fixed with screws).
- Connect the yellow RS232 cable to the new input board.



On the input board, there are two connectors where the RS232 cable could be plugged in, but only one is the correct one! Make sure to plug the yellow RS232 cable to the connector nearby the RS232 out interface!

- Plug in the red power cable.
- Place the input board in the electronic frame.
- Connect the flex foil cables. Make sure that the flex foil is inserted straight and the connector is properly closed!
- Fix the board with the four fixation screws.
- Tighten the screws of the interfaces of the electronic frame. Mind that you have to use the new screws to fix the DVI interface!



- Put the electronic frame in the ESD protective bag.
- Attach the wrist wrap to the projection unit and discard your body's electrostatic charge.
- Unpack the electronic frame and install it in the projection unit.
- Plug in the cables **EXCEPT** for the data cable!
- Switch on the projector.
- The selected background is displayed (color bars, black, blue).
- Program the input board via the OSD: select **Service | Maintenance | Program Input Board**.
- Now you can plug in the data cable and attach the rear cover.

8.5 Cleaning of the projection unit



The procedure described below shall not be performed without having participated in the respective training! Violation of this pre-condition will inevitably lead to considerable damage of the optical components of the projection unit!



Optical components are highly sensitive! Utmost care has to be taken not to scratch the surfaces!

The cleaning procedure has to be carried out in a well-lit, clean, dustfree and smokefree area!

About cleaning of the projection unit

In operation, the optical components employed in OverView D need to be cooled. In spite of filtering the air flow for cooling in advance, dust particles might reach the inside of the projection unit and pollute it. Since dust on optical elements considerably reduces the light flux, cleaning of the projection units might be necessary.



Projection units which have been operated more than 3 months with the filter pad RSPSI28422 (filter class G2) or projection units which have been operated in an environment where constructional actions or renovations are carried out are best guesses to require cleaning!


The cleaning procedure comprises measuring the brightness of the projection modules, de-mounting of the projection unit, de-assembling of the projection unit, blowing the projection unit with compressed air, wiping the components with Isopropane, and subsequently re-assembling, re-mounting and re-measuring.

The brightness values before cleaning and after cleaning have to be recorded, see check list in the appendix.

Required tools

- Test pattern: adjustment grid
- CAST (Color adjustment service tool) with spectrometer
- Wrist wrap
- ESD protective bag
- Protective gloves
- Torx key size 10
- Hexagon key size 3
- Shorting plug for color wheel
- Compressed air, type Aero duster 105 by Servisol
- Isopropane, 99.99%
- LCD cleaning tissue RSGBP26290 for optical components
- Cleaning tissue (microfibre) for metal components
- Feather duster to clean the air hoses
- Cottonwool bud

Procedure: overview



Procedure: step by step


Selecting the reference device



It is mandatory that the rear cover of the projection module is mounted so that no ambient light from the rear side distorts the measurement!

The reference device is determined using CAST. CAST is also used to see the result of the cleaning. If the entire display wall has to be cleaned, a **second** wall has to be created.

- Launch CAST
- Create a new wall
- Connect CAST to the display wall. In the connect dialog, make sure that the **Infrared control** checkbox is ticked! (You will need the IR Remote Control to read the projector runtime).



- Since it is a new wall, **lamp optimization** is performed.
- Select **Wall | Measure**
- Make sure that the CAST spectrometer is positioned in the center of the displayed rectangle! Any deviations will influence the measurement result!
- CAST measures the factory colors and the native brightness of all projectors, calculates a common target and applies this target to the wall.
- In the table view, select **factory colors** to see the native values of all projectors.

demoroom wall1 - Barco CAST-D

File Wall Lamp Tools Help

P	L	Lum	White	w	Red	r	Green	g	Blue	b	s
A01	T	219	0,196 / 0,489	001	0,421 / 0,533	019	0,139 / 0,554	003	0,159 / 0,173	007	0
B02	T	226	0,196 / 0,492	002	0,406 / 0,536	004	0,140 / 0,556	003	0,161 / 0,168	011	0
B01	B	203	0,197 / 0,489	001	0,411 / 0,535	008	0,140 / 0,557	004	0,164 / 0,163	016	0
A01	B	201	0,196 / 0,491	001	0,417 / 0,534	014	0,141 / 0,555	002	0,161 / 0,170	009	0
B01	T	207	0,196 / 0,489	002	0,412 / 0,535	010	0,138 / 0,557	005	0,164 / 0,163	016	0
B02	B	230	0,196 / 0,493	003	0,405 / 0,537	003	0,141 / 0,556	003	0,162 / 0,167	012	0
A02	T	201	0,193 / 0,487	004	0,414 / 0,534	011	0,135 / 0,554	007	0,163 / 0,164	015	0
A02	B	203	0,192 / 0,489	004	0,410 / 0,535	007	0,137 / 0,555	006	0,166 / 0,158	021	0



Make sure to compare the average values (lamp top / lamp bottom) of one projector! Depending on sorting, the values of a projector are not displayed in subsequent rows.

- Select the darkest projector (in the example its A02).
- Check if this projector has an operation time which is representative for this display wall (by means of the IR Remote Control unit, activate the OSD, and select **Lamps|Runtimes**) has been operated in its current position during these operation hours
- If confirmed positive, this projection unit becomes your reference. If negative, select the second darkest projector and check these criteria. Proceed accordingly.
- **Write down** position, serial number of the reference projector, operating hours of the projector, and brightness of this projection unit, cf. check list in appendix.



It's mandatory that you write down the values. After cleaning, when re-measuring, the values will be overwritten!

- Disconnect CAST

In the following, the projection unit referred to is the reference as selected during this step.

Preparation of cleaning

- Switch the projection module to standby.
- Remove the mid rear cover.
- Disconnect the two air hoses from the projection unit and the illumination unit, respectively, and pull the free end outside the dark box.
- Switch on the projector.
- Remove the filter pad.
- With the fan running, blow the fan about 1 minute with compressed air to clean it



Since cleaning the fan requires that the projection unit is installed and functioning, it is wise to clean the fan before de-installing the projection unit.

- Switch the projector to standby.
- Switch off the mains.
- To prevent the electronic components from damage due to electrostatic discharge, wear a grounded wrist wrap and discharge your body's static electricity by touching a grounded surface.
- Unplug all cables from the projection unit.
- Unplug the power cable from the wall outlet.
- Apply the cover onto the lens. De-mount the projection unit and put it into an ESD protective bag to prevent it from electrostatic damage.



Cleaning of the projection unit has to be done in a well-lit, clean, dust free and smoke free area.

Make sure to wear rubber (latex) gloves (sweating fingers risk corrosion!) and the wrist wrap to prevent the equipment from damages caused by electrostatic discharges.




Isopropane is highly flammable! The cleaning procedure may only be performed when the projection unit has totally cooled down, otherwise there is a danger for explosion!

Isopropane is irritating for the eyes!

Optical components of an OverView D projection unit

The following pictures show an overview about the optical components of a projection unit and also a detailed view of the respective components.


These parts have to be cleaned with the utmost care as described below!




Look at the individual pictures below to see which surfaces have to be cleaned!

Color wheel


The color wheel cartridge has to be removed in order to clean the color wheel.

*Dimmer wheel*



The dimmer wheel is a mechanical component

*Condenser lens 2*


The condenser lens 2 collects the light emitted by the lamp of the illumination unit.

*Light pipe*

The light pipe is the most sensitive part of the projection unit and may never be touched!



*Relay barrel*

The relay barrel is composed by multiple lenses.





Lens of TIR prism

TIR stands for Total Internal Reflection.






Folding mirror

The folding mirror is not allowed to be touched!
Only blow it with air!



De-assembling of the projection unit


- De-mount the color wheel cartridge. As soon as the yellow 3-pole cable of the color wheel is disconnected from the color wheel connection board in the projection unit, apply the shorting plug to prevent the color wheel from damage of electrostatic discharge!





- Unplug the cable of the IR sensor.
- Remove the electronic frame: Disconnect the two flex foil cables, the power cable and the cable from the color wheel connection board.



Use the shorting plug to prevent the color wheel connection board from damages due to electrostatic discharges!



- Loosen the screws and de-mount the electronic frame.



- Remove the cover of the air hose connection of the projection unit. Remove the entire housing.
- Probably you can already see the dust and soil on the components.

General cleaning instructions



Be very careful when cleaning optical components! Be sure to follow the instructions listed below!

There are some components which must never be wiped due to the very delicate optical coating!
If in doubt, only blow them with compressed air!

Blowing with compressed air has to be done very carefully: the can may never be tilted or turned upside down, and it has to be ensured that now liquid is dispensed.



Never tilt the can!

Never turn it upside down!

Always held the aerosol upright, and don't move it while directing the air flow to the surface to be treated.

1. Compressed air cans work as long as you are very careful to keep them level so they don't spew compression gasses.
2. Take your time and work meticulously !!
3. Take care not to shake the can while you are using it !!
4. Be sure to release a little air before using it on the optical surface.
5. This will assure that no liquid is dispensed to make things worse !!
6. Always use a new cleaning wipe!
7. Apply the cleaning wipe very softly and without pressure!

Cleaning of the components



Be very careful when cleaning optical components! Be sure to follow the instructions listed below!

How to clean optical components

The following steps have to be performed in the given sequence!

1. Take care to use the air can in an upright position! Otherwise you will spray liquid which will apply a permanent film!!
2. Blow away any coarse dirt particles with air blower.
3. Moist the LCD cleaning tissue with Isopropane, but do not soak it!
4. Be careful to not scratch the optic by applying too much pressure during cleaning
5. Start at the center of optical element and perform circular motions, working towards the edge of the optical element.
6. Immediately after passing with the moisted tissue, gently wipe off any excess liquid with dry LCD cleaning tissue.
7. In case the LCD cleaning tissue left some fluffs or lints: use air blower to blow off
8. Check to see the surface is clean using a loupe (eyepiece upside down)
9. If not clean, repeat procedure again with a newly LCD cleaning tissue.

- Gently blow compressed air on all optical components to remove dust particles: the color wheel, the condenser lens 2, the light pipe, the relay barrel, the lens of the TIR prism, the folding mirror, and the projection lens. Also blow compressed air on the PCBs inside the projection unit.
Make sure to use the air can upright!



Isopropane is highly flammable! The cleaning procedure may only be performed when the projection unit has totally cooled down, otherwise there is a danger for explosion!



Isopropane is irritating for the eyes!

- Tear the LCD cleaning tissue in two halves: One half for wet cleaning, the other one for drying up. Subsequently clean the optical components with the tissue moistened with Isopropane. Keep in mind NOT to wipe the light pipe and the folding mirror!. Gently dab the surfaces in circles, starting in the mid. Be careful not to scratch them! Then apply a dry part of the tissue in order not to leave streaks.



Do not wipe the light pipe! This will result in misalignment! With the light pipe, cleaning has exclusively be done by blowing!

Do not wipe the folding mirror!! In case it is not clean after blowing with air, the projection unit has to be sent to BCD Kuurne for repair! Only BCD Kuurne is allowed to to other cleaning procedures than blowing with air!



- To clean the metal parts, use the microfibre tissue.



Re-assembling the projection unit

- When all the components are cleaned, assemble the projection unit in the reversed order.



When connecting the two flex foil cables, make sure that the flex foil is inserted straight and the connector is properly closed!
Do not touch any contacts.

- Put on the cover on the lens.
- Put the projection unit back in its ESD protective bag.

Cleaning of the dark box and re-mounting the projection unit into the dark box

- Check the inside of the dark box and the mirror. If required, use a clean microfibre tissue, start cleaning the screen and proceed cleaning all other parts of the dark box!
- Disconnect the air hose from the fan and clean it using a feather duster
- Clean the fan with a microfibre tissue.
- Install a new filter pad.




When mounting the projection engine, also mind to wear the wrist wrap!

- Re-install the projection unit
- Plug in all cables.
- Attach the air hose to the fan and the projection unit.
- Startup the projector.
- Apply the grid and adjust it.
- Attach the rear cover

Validation of cleaning

- Launch CAST
- Open the wall you created before cleaning.
- Connect CAST.
- In the grid view, select the reference projector (the one you cleaned) (A02 of the example).
- Select Lamp | Exchange
- The following dialog pops up:



- Since you do not want to change the serial number of lamp nor the lamp runtime, make clear that the checkboxes on top of the dialog are cleared!
- Check Repeat lamp optimization
- Check Reset measurements
- This will discard all measurement values of the reference projector (exactly what you want to).



This step has to be performed twice: for lamp top and lamp bottom.

Remeasure the cleaned projector by selecting **Lamp|Measure**.

When **Lamp|Measure** has been done for both lamps of the reference projector:

- Select the grid view.
- Select factory colors

The screenshot shows the 'demoroom wall1 - Barco CAST-D' window. It features a menu bar (File, Wall, Lamp, Tools, Help) and a toolbar with icons for file operations, color selection, and grid views. Below the toolbar is a table with columns for projector ID, lamp type, luminance, and color-specific data (White, Red, Green, Blue) in both raw and normalized formats.

P	L	Lum	White	w	Red	r	Green	g	Blue	b	s
A01	T	219	0,196 / 0,489	001	0,421 / 0,533	019	0,139 / 0,554	003	0,159 / 0,173	007	0
B02	T	226	0,196 / 0,492	002	0,406 / 0,536	004	0,140 / 0,556	003	0,161 / 0,168	011	0
B01	B	203	0,197 / 0,489	001	0,411 / 0,535	008	0,140 / 0,557	004	0,164 / 0,163	016	0
A01	B	201	0,196 / 0,491	001	0,417 / 0,534	014	0,141 / 0,555	002	0,161 / 0,170	009	0
B01	T	207	0,196 / 0,489	002	0,412 / 0,535	010	0,138 / 0,557	005	0,164 / 0,163	016	0
B02	B	230	0,196 / 0,493	003	0,405 / 0,537	003	0,141 / 0,556	003	0,162 / 0,167	012	0
A02	T	231	0,193 / 0,487	004	0,414 / 0,534	011	0,135 / 0,554	007	0,163 / 0,164	015	0
A02	B	214	0,192 / 0,489	004	0,410 / 0,535	007	0,137 / 0,555	006	0,166 / 0,158	021	0

Look for the values of the reference projector and write them down, cf. check list.

- Compare the values before cleaning and after cleaning: if there is a significant increase in brightness (>10%), it is worth cleaning all the projection units

Further steps

If the cleaning of the reference projection unit results in a gain of minimum 10% light output, it is recommended to clean all other projection units of the entire display wall, too.

From the wall created before, write down the **native luminance** values (**factory colors**) of all projectors, lamp top and lamp bottom, cf. checklist.

To clean the other projection units, proceed as described above, starting with **Preparation of cleaning**.



Fill in the required information in the check list!

Fill in the check list for every projection unit!

When cleaning of all projection units has been completed, re-install them in the display wall.



Make sure to re-install the projection units on their original position in the display wall!

- Launch CAST
- Create a new wall!
- Connect CAST.
- Select **Wall | Measure**.
- Make sure that the CAST spectrometer is positioned in the center of the displayed rectangle! Any deviations will influence the measurement result!
- CAST will measure the factory colors of the cleaned projection units, calculate a common target, and apply this target to the display wall.
- In the table view, select **Factory colors**. Look at the luminance values of the projection units after cleaning and write them down in the check list.
- If you look at the reference projector in the new wall and its factory luminance values, they are about the same as in the previous wall after cleaning (example: A02):

demoroom wall2 - Barco CAST-D												
File Wall Lamp Tools Help												
P	L	Lum	White	w	Red	r	Green	g	Blue	b	s	
A01	T	228	0,193 / 0,488	001	0,415 / 0,534	018	0,135 / 0,555	002	0,162 / 0,166	006	0	
A01	B	214	0,193 / 0,490	001	0,411 / 0,534	015	0,136 / 0,556	002	0,163 / 0,165	007	0	
B01	T	219	0,193 / 0,488	002	0,406 / 0,536	009	0,133 / 0,557	005	0,167 / 0,156	015	0	
B01	B	217	0,194 / 0,489	001	0,405 / 0,536	008	0,135 / 0,557	003	0,166 / 0,157	014	0	
A02	T	231	0,192 / 0,487	002	0,413 / 0,535	017	0,134 / 0,555	003	0,163 / 0,164	008	0	
A02	B	215	0,192 / 0,489	002	0,410 / 0,535	013	0,136 / 0,557	003	0,166 / 0,158	013	0	
B02	T	235	0,194 / 0,491	002	0,400 / 0,537	004	0,135 / 0,557	003	0,164 / 0,161	009	0	
B02	B	240	0,194 / 0,492	003	0,398 / 0,537	003	0,137 / 0,557	003	0,165 / 0,160	011	0	



Write down these brightness values (check list).

Store the signed checklist, and send a copy of the check list and a copy of the two wall databases to Jean-Claude Fey (mailto:jeanclaude.fey@barco.com)

<i>Information about the Barco technician</i>	
Name of Customer Support Engineer:	
<i>The above mentioned CSE has participated in the training of cleaning of a projection unit.</i>	
Date and location of training:	
Training held by:	
<i>Information about the display wall</i>	
Project No.	
Customer address	
Installation date:	
Number of rows Number of columns:	
Resolution:	<input type="checkbox"/> XGA <input type="checkbox"/> SXGA <input type="checkbox"/> SXGA+
The display wall has been operated with filter pad RSPSI28422 for more than three months	<input type="checkbox"/> yes <input type="checkbox"/> no
The display wall has been operated in an environment where constructional actions and renovations took place	<input type="checkbox"/> yes <input type="checkbox"/> no
<i>Reference contamination grade</i>	
Initial CAST measurement performed	<input type="checkbox"/>
Position of selected reference projector as indicated by CAST	
Serial number of reference projector	
Operating hours of reference projector	
Brightness values lamp top	
Initial value	
value after cleaning	
Brightness values lamp bottom	
Initial value	
value after cleaning	
Brightness improvement in percent (average)	
Cleaning of entire display wall necessary	<input type="checkbox"/>

If cleaning of the entire display wall is required, please fill in the following check list for all projection units of the display wall.

Information about the reference projection unit and all other projection units

Position (as indicated)	Serial no. Projector	Operating hrs Projector	Brightness initial value	Brightness after cleaning	Brightness gain in %
----------------------------	-------------------------	----------------------------	-----------------------------	------------------------------	-------------------------

[illegible]

8.6 Check settings of the OverView D projection system

General

The following settings have to be checked, and, if required, adjusted. This is done in the OSD in the **Production** menu.

To enter the **Production** menu, display the OSD menu bar, highlight **Brightness**. With the numeric keys on the IR Remote-Control unit, enter the password for the **Production** menu.

Pulse Factor

OSD: **Production|Pulse Factor**

The valid range for the pulse factor is from 1.1 to 1.3. If the actual pulse factor is outside this range, set it to 1.2!

Lamp Status

OSD: **Production|Lamp Status**

The lamp status has to be set to **automated regulary**.

In case the setting is different, proceed as follows:

- If required, enable Hot Standby.
- Switch to Hot Standby.
- Wait about 2 minutes for the lamps to be heated up.
- With the active lamp, select **Production | lamp status | automated now**
- Change the active lamp.
- With the second lamp, select **Production | lamp status | automated now**
- Subsequently select **Production | lamp status | automated regulary**.
- Switch to the former valid operation mode.
- If at the beginning it was necessary to enable **Hot Standby**, disable it again.

Dimmer check

L slit and S slit

OSD: **Production|Dimmer|Adjust L slit** and **Production|Dimmer|Adjust S slit**

The valid range for L slit is 3200 to 3240

The valid range for S slit is 3455 to 3495

In case the S slit position is out of range but within the range of the L Slit position and vice versa, they have been mixed up. Write down the values, and exchange them.

If the values don't fit to any range at all, data must be read back from production data base or must be readjusted according the adjustment procedure AA-PR-DLP-006.

Maximum Brightness

OSD: **Production|Dimmer|Adjust Max. Brightness**

The valid range for the max. brightness is from 2590 to 2630. In case the value is out of range, set it to 2610.

8.7 Illumination unit 200W: replacing the fan plate.

This document refers to the illumination unit 200W of the OverView D series, R764463 and R9842770

Summary



The illumination unit 200W employs additional fans for cooling located on the right side of the lamp housings (top and bottom lamp).

When replacing a lamp, the connection cables to this fan might get hurt during the re-insertion of the lamp module.


Therefore the fan plate has been redesigned to avoid the risk of damaged cables.

The old fan plate has to be replaced by the new one. The new fan plate provides a higher shielding for the fan connection cables.

The following 2 pictures show the difference between the old fan plate (always the left "brass looking" one) and the new fan plate (always the right, "steel looking" one):





When installed, the fan plates manifest in a different way to guide the fan connection cables. The picture on the left shows the cable guide to the fan with the old fan plate. The picture on the right shows the cable guide with the new fan plate.





Replacement procedure

To replace the fan plate, proceed as follows:



- Switch the projector to standby.
- Power off the system
- Open the bottom (top) lamp door.
- Remove the bottom (top) lamp to get access to the fan and the fan plate.
- Disconnect the fan (unplug the two-pole connector).
- Use a torx key size 10 to loosen the screw fixing the fan to the lamp housing.
- Remove the fan.
- De-mount the old fan plate from the fan.



- Attach the new fan plate to the fan.



- Use a torx key size 10 and fix the fan into the bottom (top) lamp housing.
- Plug in the two-pole connector to connect the fan.



- Insert the lamp module and close the bottom (top) lamp door.
- Power on the system and switch the projector into operation.

9 Partslist



This manual refers to specific versions of products. Please check if this product correlates with the respective product in the field. Not all versions can be covered here. If in doubt please contact your responsible support center.

9.1 Consumables

Article Number	Description
R9842020	OV D LAMP 1 PC, 120W
R9842440	OV D LAMP 1 PC, 100W
R9842800	Filter Pad

9.2 Spare Parts (Sales Articles)

Article Number	Description
R9841920	OV D SPARE PROJECTION UNIT SXGA
R9841921/R98419215	OV D SPARE PROJECTION UNIT XGA
R9842670/R98426705	OV D SPARE PROJECTION UNIT SXGA+
R9841940	OV D SPARE ELECTRONICAL FRAME ASM XGA/SXGA; Firmware 1.x, 2x
R9842820	OV D SPARE ELECTRONICAL FRAME ASM XGA/SXGA+; Firmware 3x
R9842790	OV D SPARE COLOR WHEEL CARTRIDGE XGA/SXGA
R9842791	OV D SPARE COLOR WHEEL CARTRIDGE SXGA+
R98442460	OV D SPARE ILLUMINATION UNIT 100W
R9842650	OV D SPARE ILLUMINATION UNIT 120W
R9842470	OV D SPARE ILLUMINATION UNIT 120W
R9841970	OV D SPARE MIRROR UNIT ASSEMBLY XGA/SXGA
R9841980	OV D SPARE LIFT MOTOR ASSEMBLY XGA/SXGA
R9841990	OV D SPARE SM POWER SUPPLY + PFC XGA/SXGA
R9842000	OV D SPARE LAMP POWER ASSEMBLY XGA/SXGA
R9842010	OV D SPARE CONTROL ASSEMBLY XGA/SXGA
R9842030	OV D CABLE PU - IU 1PCE
DLP-3278-01	OV D FAN BOX REPAIR KIT (or earlier description)

9.3 Spare Parts (internal products, not for sale)

Article Number	Description
R763938	Formatter Board, XGA
B400610	DLP 1 CH XGA chip
R763769	Formatter Board, SXGA
B400548	DLP 1 CH SXGA chip
V322050	Internal fan
R314520	Fuse, Type F A H+C 10A 5X20 BV
K314103	Fuse, Type F 5X20 T 3A15 H UL

10 Hotline

10.1 Addresses

Please feel free to contact us if you encounter any problems.

- **Barco Control Rooms GmbH**
An der Rossweid 5, D-76229 Karlsruhe
Phone: +49-721-6201-0, Fax: +49-721-6201-298
E-mail: info.de.bcd@barco.com, Web: www.barcocontrolrooms.de
- **BARCO N.V. Projection Systems**
Nordlaan 5, B-8520 Kuurne
Phone: +32-56-368-211, Fax: +32-56-36 82-82
E-mail: support.controlrooms@barco.com, Web: www.barcocontrolrooms.com